

# 9L VACUUM OIL/FLUID EXTRACTOR

81315

## **SPECIFICATION**

Stock no8	31315
Part no M	FE9L
Reservoir capacity	
Dimensions	m (H)
Hose dimensions;	30mm
6mmØ x 113	
10mmØ x 112	
Nett weight (empty)	

### SAFETY INSTRUCTIONS

- · Always wear ear and eye protection.
- · Used engine oil is carcinogenic wear protective gloves.
- · Always store in an upright position in a secure place.
- · Keep out of the reach of children.

#### **EXTRACTOR OPERATION**

**NOTE:** Prior to connection consult vehicles handbook or Haynes manual as this may not be suitable for all vehicles.

**OIL EXTRACTION:** Ensure the vehicle is on level ground before use. Select the most suitable nozzle for the job in hand and insert into the pickup hose.

Remove dipstick and insert tube fully down the dipstick tube, raise the handle to the highest point and pump several times full strokes to create a vacuum. This will create a consistant and automatic flow.

**RELEASING PRESSURE:** To release the pressure simply push down on the spring loaded safety pressure release valve until the pressure has completely dropped.

**NOTE:** Do not allow waste fluid types to mix in the reservoir. Dispose of waste fluids in accordance with the relevant environmental health and safety guidelines.

To empty the reservoir, remove the reservoir cap and pour into a suitable storage/transport container.

## **IDENTIFICATION**

- ① Probe 1 4mmØ x 1130mm
- ② Probe 2 6mmØ x 1130mm
- ③ Probe 3 10mmØ x 1120mm



