

*Armitage
Shanks*

Markwik 21+ Safe SQ Sensor operated thermostatic mixers

INSTALLATION INSTRUCTIONS



**UK
CA**



**A6684AA Markwik 21+ Safe SQ
panel mounted mixer, sensor
operated – timed flow (demountable)
with removable spout & Armitage
Bioguard outlet.**

**A6737AA Markwik 21+ Safe SQ
panel mounted mixer, sensor
operated – timed flow (demountable)
with fixed spout & Armitage
Bioguard outlet**

Important:

1. **Electrical connection:** these mains powered sensor operated products must be connected to a continuous permanent power supply.
2. **Sensor protector:** this black-out lens cover should only be removed from the sensor after completing installation & at least 10 seconds after powering up.

See page 3 for more details.

IMPORTANT

BEFORE CONNECTION, FLUSH WATER THROUGH PIPEWORK TO REMOVE ALL DEBRIS ETC. WHICH COULD DAMAGE THE VALVE MECHANISM

INSTALLER: After installation please pass this instruction booklet to user




TABLE OF CONTENT

1	TABLE OF CONTENT	2
2	IMPORTANT PRE-INSTALLATION NOTES	3
2.1	DESCRIPTION	4
3	PRODUCT BOX CONTENTS	5
3.1	TIMED FLOW MIXER DIMENSIONS	6
4	WATER SUPPLY CONDITIONS	7
4.0	WATER REGULATIONS	7
4.1	INTRODUCTION	7
4.2	SUPPLY PRESSURE REQUIREMENTS	7
4.3	HEALTHCARE ESTABLISHMENTS	7
5	INSTALLATION: FIXATION	8
6	INSTALLATION: PLUMBING	8
6.1	FLUSHING	11
7	INSTALLATION: ELECTRICAL	12
8	MIXER OPERATION	15
9	SENSOR CONFIGURATION	15
9.1	DETECTION RANGE ADJUSTMENT	16
9.2	RUN TIME ADJUSTMENT	16
9.3	FACTORY RESET	17
10	COMMISSIONING AND AUDITS	17
10.1	THE PURPOSE OF COMMISSIONING:	17
10.2	COMMISSIONING PROCESS	17
10.3	AUDIT CHECKS ON TMV'S	17
10.4	AUDIT PROCEDURE	19
10.5	IN-FIELD 'COLD WATER ISOLATION'(CWI) TEST	20
10.6	SETTING TEMPERATURE FOR SENSOR OPERATED MIXERS	21
11	SERVICING - TYPE 3 SCHEME	21
11.1	FREQUENCY OF REGULAR SERVICING	21
12	MAINTENANCE OF IN-LINE COMPONENTS	21
13	MAINTENANCE	22
13.1	ADJUSTMENT OF THE MIX TEMPERATURE:	22
13.2	REMOVAL AND INSPECTION OF CARTRIDGE	22
13.3	IMPORTANT NOTES ON DEBRIS	23
13.4	THERMOSTATIC CARTRIDGE AGEING	23
13.5	ARMITAGE BIOGUARD OUTLET	23
13.6	MAINTENANCE CLEANING	23
13.7	HYGIENE FLUSH (AUTOMATIC)	24
13.8	SOLENOID VALVES	25
13.9	SPOUT REMOVAL	26
13.10	DEMOUNTING MIXER	27
13.11	DISINFECTION SOLUTION	29
13.12	STRAINERS	30
14	INTEGRAL ISOLATION VALVES	30
15	COMBINED CHECK VALVE REGULATORS	31
16	MARKWIK 21+ ACCESSORIES	32
17	SPARE PARTS - ELECTRICAL	33
18	SPARE PARTS	34
	SPARE PARTS LIST - MIXER	35
19	CLEANING CHROME SURFACES	36

2 IMPORTANT PRE-INSTALLATION NOTES



MAINS ELECTRICAL POWER SUPPLY

Mains powered Sensor Operated Products must be connected to a (fused / switched) **continuous permanent power supply**. This can be by a fused spur or a fused & switched spur. Installing a switch will permit easier future maintenance of the electrical system

Connection to an **interrupted power supply** intended to stop electrical consumption in an unused facility, may adversely affect this sensor product and is therefore not recommended.

Each time the power supply is reinstated the product briefly enters installation & then calibration phases.

During the calibration phase, any interaction (passive or active) with the product may alter the sensor settings in respect to range and / or run duration. So avoid activity in the detection zone.


No significant savings will be achieved by connection to an interrupted supply. These products are intrinsically economical in terms of both water and electrical energy and will shut down in the event of a sensor being obstructed. In this case, the sensor will permit water to run for 55 secs max. Sensor settings are stored & automatically retrieved in the event of a power failure

SENSOR LENS PROTECTIVE COVER (PEELABLE BLACK STICKER).

This product is supplied with the sensor lens covered over with a black-out material.

DO NOT REMOVE this lens cover until the product installation has been completed & then wait for at least 10 seconds after powering-up.

The lens cover prevents the sensor from unintentionally entering the calibration phase during the powering up sequence. Calibration phase will only commence once the lens cover is removed. After the installation phase, the sensor enters a power-saving mode until the lens cover is removed



**DURING SETTING UP
PROCEDURE AVOID HIGH
VISIBILITY CLOTHING**



2.1 Description



Markwik 21+ Safe SQ panel mounted mixers (demountable) with fixed or removable spout & Armitage Bioguard outlet

A6684AA

Markwik 21+ Safe SQ mixer, sensor operated -removable spout – time flow

A6737AA

Markwik 21+ Safe SQ mixer, sensor operated - fixed spout – timed flow

This manual covers the Markwik 21+ range of time flow operated, panel mounted, thermostatically controlled mixers. These are designed to provide water at a preset temperature for hand washing. The time flow controls allow operation of the flow without the user having to touch the mixer.

These products are fitted with an Armitage Bioguard outlet which reduces the opportunity for bio film attachment and is lined with anti-microbial copper.

A hygiene flush (automatic) is an important optional feature of these products which can be enabled by the installer or maintenance staff. The hygiene flush is used to combat periods of low usage of the product. The program monitors and permits the fitting to be run automatically if it hasn't been used for a set time period. This feature ensures regular movement of water preventing stagnation, thus combating bio film growth and bacteria colonisation.

See section 13.7 for more details.

Two timed flow models are covered one with removable spout and one with fixed spout

Flow starts when the user's hand enters the detection zone and shuts off after a pre-set time. The pre-set time can be adjusted. Traditionally the sensor is mounted to the right of the fitting, but it can be mounted to the left if necessary.

They are both intended to be installed on duct panel walls.

The panel thickness should be in the range 13 - 27 mm. Two holes, of diameter 30mm nominal and one at 35mm nominal, will need to be cut in the panel at centres defined in Figures 1 & 4

The hot side of the mixer is insulated to ensure the body surface is maintained at a safe temperature when the fitting is in operation.

These mixing valves are supplied complete with integral isolating valves, strainers, check valves and flow regulators. They have a built-in thermal shock feature, using the special tool provided, the maximum blend stop to be overridden up to the full hot water supply temperature in the system.

These Markwik 21+ products permit quick & easy removal of the mixer. The spout can also be removed for cleaning, disinfection & maintenance purposes on mixer A6684AA.

Dry testing & protective caps

These products are delivered to our customers in a dry state. Water testing of these products at the factory has been replaced by air testing, using clean dry filtered air. After testing, both inlets & the outlet are fitted with protective caps to prevent environment contamination entering the product during transit



Abbreviations & terminology used

PSU: Power Supply Unit - mains version only.

PCB: Printed Circuit Board - inside the PSU.

RCD: Residual Current Device.

SELV: Safety Extra Low Voltage


IR: Infrared (sensor technology)

LED: Light Emitting Diode


Factory settings




3 PRODUCT BOX CONTENTS




Fixing kit for mounting mixer. Includes 2 off each: back plates, o-rings, slip washers & back-nuts.



1x Markwik 21+ mixer body with lock shield fitted




1x Sensor kit complete



1x Velcro pad set



2x Inline service valves with strainer




2x Solenoid valves



2x Couplers
G1/2" female thread to 15mm compression



1x SV link cables (pair)



1x Power Supply Unit (mains)

3.1 Timed Flow Mixer Dimensions




Figure.1 Height positioning of fitting over “waste appliance”

IMPORTANT: Prior to installing mixer, ensure that any existing thermostatic mixing valves (TMVs) that may be fitted are removed

4 WATER SUPPLY CONDITIONS

4.0 Water regulations

The fittings covered by this installation and maintenance instruction should be installed in accordance with the Water Regulations published in 1999*, therefore Armitage Shanks would strongly recommends that these fittings are installed by a professional installer.

*A guide to the Water Supply (Water Fittings) Regulations 1999 and the Water Byelaws 2000, Scotland is published by WRAS (Water Regulations Advisory Scheme)
Unit 13, Willow Road, Pen-y-Fan Industrial Estate, Crumlin, Gwent,
NP11 4EG. ISBN 0-9539708-0-9

4.1 Introduction

These timed flow thermostatically controlled mixers are manufactured to the highest standards and have approval to Type 3 which permits them to be installed in healthcare establishments such as hospitals, nursing homes and residential care homes. When installed in healthcare establishments the supply conditions detailed in Table 1 must be observed and the commissioning and servicing requirements detailed on section 10 & 11 must be followed.

For other installations this is not a requirement.

4.2 Supply Pressure Requirements

This mixer is designed to be installed on all types of plumbing systems.

Hot and cold water supply pressures should be reasonably balanced, however, the mixer will function within specification on unequal pressures up to 5 :1.

The mixer has integral isolating valves which permit servicing of the strainer, combined check valve regulator & thermostatic cartridge. They are also used for Cold water isolation testing.

Flow Rate Improvement for pressures below 0.6 bar (60 kPa):

Remove the Ø10mm flow regulated check valves from the inlets (see Section 12).

Important: Do not remove the Ø15mm check valves inside the inlet bores.

4.3 Healthcare Establishments

In accordance with the NHS model engineering specifications DO8 this valve has approval for the following applications:-

High Pressure	HP-	-WE
Low Pressure	LP-	-WE

For this type of application the following supply conditions must apply:

Operating pressure range:	High Pressure	Low Pressure
Maximum static pressure	10 bar	10 bar
Flow pressure hot and cold	1 to 5.0 bar	0.2 to 1.0 bar
Hot supply temperature	55 to 65 °C	55 to 65 °C
Cold supply temperature	5 to 20 °C	5 to 20 °C

Note:

Fittings operating outside these conditions cannot be guaranteed by the scheme to operate as **Type 3**.

Table 1 Supply conditions for healthcare establishments

Effectively this means:

Differential between HOT and COLD inlet temperatures (Δt) must be 35°C min and 60°C max

Differential between HOT inlet temperature and MIXED temperature (Δt) > 14°C preferred

See 10.3 Audit checks on TMV's.

5 INSTALLATION: FIXATION

These mixers are designed to be panel mounted on a duct wall of maximum panel thickness 27mm. For thicker panels the rear of the panel will require counter bores of 62mm or greater around the fixation holes.

Cut two holes of 30mm diameter, horizontally aligned to 200mm centres in the wall.
(See figure 1 for height positioning of the fitting body over a “waste appliance”)

The sensor will require a hole of 35mm positioned as indicated in fig4.

Loosen the chrome shrouds and insert the fitting as shown above with the wall plates and seals to the front of the wall. Put on the slip washers and do up the backnuts to a torque of 25 Nm Screw the shrouds onto the wall plates




Figure 4 Timed Flow mixer installation - panel mounting

6 INSTALLATION: PLUMBING

Products covered in this manual are certified with the service valves provided.

Only if necessary (not recommended), use an equivalent service valve with integral strainer & isolating function.

NOTE FOR IRELAND: 15mm olives are supplied with this product. Use ½" olives if ½" supply pipes are fitted.

First refer to section 4. Supply conditions.

A typical example of an installation of a mixer is shown here as a guide. In this example, the water supply pipes are provided from above (this usually permits better drain down of pipes). Supplies can be from any direction.

This diagram shows the preferred method of assembling the plumbing components. Two of these assemblies are required per product. **OBSERVE ARROWS ON VALVE BODIES.**

IMPORTANT: Avoid using heat for soldering near the product inlets to prevent damage to internal components




Fig 5 Overview of plumbing installation

Mount mixer to the panel and secure the backnuts.

Fit swivel elbows (15mm x G1/2, not supplied) to the inlet tails as shown and ensure the seals supplied with them are fitted between the inlet tails & the elbows. Make good the joints.

Prepare two short lengths of 15mm copper pipe (minimum of 45mm long) and assemble to the compression side of elbows. Make good the joints

IMPORTANT: When viewed from the REAR, the HOT supply should be connected to the RIGHT hand side.

Fig 6 View from rear of proximity product showing it fixed to panel with backnuts, swivel elbows & copper tails

The coupling nuts (supplied) can now be screwed onto both sides of both in-line solenoid valves. Ensure the seals provided are fitted between the solenoids and the coupling nuts. Make good the joints, taking care not to use excessive force.

solenoid coil is on a ratchet - permitting rotation of up to 90 deg in either direction about the horizontal axis shown

solenoid valves can also be rotated about the vertical axis into a position that permits easy access to connectors





Fig 8 View from rear showing solenoid valves fitted onto copper pipes



The solenoid valve assemblies can now be loosely fitted onto the copper pipes.

IMPORTANT: Ensure directional arrow on valve body follows the direction of the water flow.

Position solenoid valves as required and then make good the joints

DO NOT apply heat near this product. Heat generated by soldering could damage plastic parts and seals.

Check that all joints are securely tightened, test for leaks.



Installation: plumbing continued...

IMPORTANT: Ensure the arrows on the valves bodies match the direction of the water flow.




Fig 9 view from rear showing

Connect water supply pipes to the service valves and make good all the joints. Check that all connections are water tight.





Fig 10 View from front showing service valves fitted to pipework

6.1 Flushing



IMPORTANT NOTE:

Before operating the product, it is strongly recommended to flush the pipe work to remove any residues or debris remaining after installation. A purge kit is available for this purpose. **(See section 16)**

The purging kit also provides the facility to obtain water supply temperatures at the inlets

Safety Note: Care should be taken when carrying out the following procedure to avoid contact with hot water and hot surfaces. We recommend the use of protective hand wear.

The following procedure should be used to flush out the pipework:

1. Remove the strainer from the inlet with a 5mm hexagon key to gain access to the purging port. **(See section 13.12)**
2. Screw the purging kit into the inlet port fully and then unscrew until the small indent on the purging kit towards the front of the inlet as shown.
3. Open the isolating valve and allow water to discharge into a vessel until the water flows clean. Suitable tubing can be push fitted onto the purging kits if required.
4. Repeat on the both sides of the mixer so that the hot and cold supplies are both flushed

Once the system has been flushed, remove the purging kits and refit the strainers using a 5mm Allen key. **DO NOT OVER TIGHTEN**, observe torque setting shown in section 13.12 .

Re-assemble the Chrome Inlet Sleeves and Panel Shrouds and secure the body back onto the inlets with a 3mm hexagon key..

7 INSTALLATION: ELECTRICAL

ELECTRICAL SAFETY

IEE (BS 7671) In the interest of electrical safety, ensure all wiring conforms to the latest standard UK IEE Wiring Regulations.

Always ensure mains power supply is switched off before commencing any electrical connection work.




Fig11 Showing overview of electrical installation

Connection of this product to mains power supply should be undertaken by a competent person.

A typical example of an installation of a mixer is shown here as a guide.

Orientation & position of solenoids, and PSU (Power Supply Unit) case can differ from installation to installation.

An overview of the electrical wiring is shown in Fig 11

With the product securely mounted to the panel & plumbed-in, electrical work can commence.




Fig13 View from rear showing solenoid valves link cable fitted




Fig12 View from rear showing one of the solenoid valves


First connect the two solenoid valves together using the separate link cable provided. The link cable is black & red with connectors fitted at both ends. Cable length is 500mm.

Connect the cable to the solenoid valve terminals as shown. Observe the + and – symbols marked on the solenoid valves, connect the red cables to + & black to –.

Note: one end of this link cable is fitted with additional spade connectors as shown. These connectors are for attaching the red & black sensor cable.

NOTE: Children must not be allowed to clean or maintain this product

Installation: electrical continued...



Locate the end of the red & black cable which is attached to the rear of the sensor. Cable length is 800mm.

Connect this cable to the spade connectors shown on the link cable. Observe + and – Ensure red is connected to red & black to black.

Fig14 View from rear showing sensor cable fitted to one solenoid valve

Next, open the PSU case by unscrewing 4x posi-drive screws; the lid & seal should separate from the PSU case. Slide out the PCB (Printed Circuit Board) from the case.

With the mains power switched off, prepare the mains power cable (not supplied). This should be flexible 3A rated 2 core cable. Carefully remove about 100mm of outer cable sheathing, strip the wire ends back by about 5mm.

Feed the cable through the grommet at the base of the case (cut small slot in grommet first).

Connect the appropriate mains wires to the L (Live) & N (Neutral) marked on the terminal block on the PCB.

Slide the PCB back into the case (note guide slots), allowing the mains wires to rest in-front of the transformer.

DO NOT leave wires on top of the transformer as this may prevent the lid from closing completely




Fig15 Power Supply Unit (PSU)

Installation: electrical continued...

IMPORTANT: Ensure terminal block screws are firmly tightened & clamp the wires securely.
Note earth connection is not required to PCB

Locate the end of the second cable (grey & black) which is attached to the rear of the sensor (cable end has connector fitted, length is 800mm). The cable can be slid into the upper grommet (which is pre-slit) & fed through the lid.

Plug this cable into either one of the two connectors on the PCB. The lid can now be closed, ensure the grommet is pressed into the lid. Check that no cables are trapped under the lid, make sure the lid seal is in place, and then refit the 4 retaining screws.

A pair of self-adhesive Velcro-type pads are provided. Attach one to the side of the PSU case & the other to a suitable location on the rear of the mounting panel.


Note: ensure the selected location does not stretch/stress the cables. Consideration should also be given to keeping the PSU case within easy reach/access for maintenance staff. Fasten the PSU case to the mounting panel.

This completes the behind-panel installation work.

IMPORTANT: Leave the sensor protective sticker in place for at least 10 seconds after powering-on the product.
See section 9 regarding sensor configuration



Electrical information & approvals:




Power: **6W**

Input voltage range:
100V - 240V~ 50 - 60Hz


Protection class: **II**

Approval EU:
EN 60950, EN 60335

Approval UL: **UL 1310**



DIN EN 60730-1: Type 1




8 MIXER OPERATION

Operation

Both mixers are operated when the user places a hand in the detection zone.

Flow will then continue for a preset time of 60 seconds and then stop automatically. The preset time can be adjusted by following the procedure outlined in the section on configuration of the sensor below.



For cleaning operation see section 19, & for quick flush operation see section 13.7

Figure 16

9 SENSOR CONFIGURATION




Upon completion of installation, both plumbing & electrical, the product can be powered up. The product is designed as “plug & play” system. So to get the product up & running quickly, follow these simple steps:

- Switch on power supply
- Wait 10 seconds
- Peel off protective sticky sensor cover (first time power-up)
- Keep the detection area clear of any objects for at least 10 seconds.
- The sensor will enter **NORMAL OPERATION**, the product is now ready to be used



**DURING SETTING UP
PROCEDURE AVOID HIGH
VISIBILITY CLOTHING**

To enter the **CONFIGURATION MENU**, power off for 10 sec & power on, wait another 10 sec as follows:



By covering the sensor with a finger for a given time, this will trigger one of the menus shown below. Each time 5 sec segment of time has elapsed, the product will provide a 2 sec confirmation flush. So, at 15 sec, the tap will be at the third confirmation flush, removing the finger immediately, will enter run time adjustment menu.

1st flush @ 5 sec **DETECTION RANGE**: permits adjustment of $\pm 20\%$.


2nd flush @ 10 sec **24H HYGIENE FLUSH**: toggle on or off.

3rd flush @ 15 sec **RUN TIME**: 15, 30, or 60 sec overrun time.


4th flush @ 20 sec **RESET**: all values returned to original factory settings

Once invoked, the configuration menu remains active for 3 minutes (180 sec).

SENSOR CONFIGURATION continued...



9.1 DETECTION RANGE ADJUSTMENT




Follow steps 1 to 4, cover the sensor with a finger for 5 sec. Remove finger after the first confirmation flush. Assuming previous setting was factory set, the next option will be set at the range plus 20%, LED will give 3 flashes.

For example, the range is factory set 120, this will increase to 160. (In this case 20% = 40mm). To reduce the detection range to 80mm, enter this menu again.


9.2 RUN TIME ADJUSTMENT

This run time sets how many seconds the water overruns after hands have moved out of the detection zone.



Follow steps 1 to 4, cover the sensor with a finger for 15 sec. Remove finger after the third confirmation flush. Assuming previous setting was factory setting of 60 sec, the next option will be set at 15 sec, & the LED will give 1 flash.

9.3 FACTORY RESET



10 COMMISSIONING AND AUDITS

The following procedure should be conducted after installation to ensure the product is functioning correctly.

10.1 The Purpose of Commissioning:

- To confirm the correct designation of product versus application.
- To confirm the correct supply water conditions for the product / installation.
- To adjust the mixed temperature if necessary to suit the water supply conditions of the installation.
- To check the product is performing properly.
- To start an audit log and record appropriate data.

This product is factory set at $40 \pm 1^\circ\text{C}$ * with supplies of circa; 3 bar balanced pressure and temperatures of 15°C cold & 65°C hot (i.e. an inlet Δt of 50 & a hot / mix Δt of 24)
For supply requirements, see 4.0 Water supply conditions.

10.2 Commissioning Process

- Establish that the supply conditions are within the requirements of HTM 04 and the supply conditions outlined above. If not investigate.
 - When conditions are acceptable record them, together with hot and cold temperatures. Establish Δt . Check the outlet mix temperature is within $41^\circ\text{C} \pm 2^\circ\text{C}$ *, if not (probably due to $\Delta t > 5$ difference to factory setting) adjust appropriately. (See section 13.1)
 - If mixed water temperature is correct undertake an 'in field' cold water isolation (CWI) test (See section 10.5).
- Pass – restore supply and record mixed temperature,
Fail – **See section 10.5 in field 'Cold Water Isolation' test.**

10.3 Audit Checks on TMV's


The purpose of a performance audit of a product is:

- To check the product continues to perform properly.
- To flag the need for the product to be adjusted due to supply condition changes or mechanism ageing.
- To ultimately identify the need for product maintenance.

Note - Additionally these audits facilitate regular verification of the supply conditions in accordance with HTM 04 requirements. (See decision tree FC3)


* See section 10.6: setting temperature

10.2 cont. Commissioning process (decision tree FC1)



* See section 10.6: setting temperature


Audit of Supplies To Fittings (FC3)



10.4 Audit procedure (see decision tree FC2)

- Verify the water supplies conditions are similar to when the product was commissioned i.e. inlet Δt as previous + / - 5°C
 Note: If inlet Δt change is > 5°C consider the cause of the change, If it is seen as a long term or permanent change, re-commission the product. If however, it is only a temporary change, retest when normal conditions resume.
- If inlet Δt differs from the commissioning Δt by < 5°C carry out field 'cold water isolation' (CWI) test as D-08: 2009. **See section 10.5 in field Cold Water Isolation test failure.**
- Pass - restore the cold supply and move on to check the mix temperature.
 Note: If the product fails CWI test, refer to 9.5 and then re-commission the valve.
- Mixed Temperature is as commissioned $\pm 2^\circ\text{C}$, Accept and record the temperature.
 Note: If mixed Deviation > $\pm 2^\circ\text{C}$ (1st instance) reset mix as instructions and redo the test from start. **See section 13.1 Adjustment of the mix temperature.**
- 2nd & subsequent instances follow maintenance instructions.

Fitting Field Test Audit (FC2)



10.5 In-field 'Cold Water Isolation'(CWI) test.

Note: To gain access to the cold water isolating

valve, unscrew the right hand shroud & slide forward to expose the isolating screw on top of the cold inlet leg.

Using a 5mm Allen Key, The isolation plug can be screwed down fully to isolate the cold water supply

Prior to commencing the CWI test, ensure:

1. The water supply conditions are met either:

A. For commissioning a new product (see table 1, section 4).

B. Or the inlet Δt is within $\pm 5^{\circ}\text{C}$ to when the product was commissioned (see 10.4).

NOTE It is important that the hot temperature is greater than 55°C

2. Mixed water outlet temperature is correct (see table 2, section 11).

To perform a CWI test, operate the product using the sensor. Then conduct the following procedure:

1. Record the steady state temperature of both hot and cold water supplies. Note the Δt .
2. Record the temperature of the mixed water at the outlet.
3. Isolate the cold water supply & monitor the flow of water from the outlet.

If the flow ceases, CWI test passed:

1. Restore the cold water supply by rotating the isolator screw 90° clockwise.
2. Slide the shroud back & screw onto the wall plate.
3. Re-check the temperature of the stabilised mixed water at the outlet to ensure it is still correct.

Accept & record mixed temperature.

If there is an ongoing flow of water from the mixed water outlet, then 5 seconds after CWI collect the discharging water into a measuring vessel for 60 seconds. To pass the CWI test the volume of collected water should be less than 120ml.

If the product fails CWI test, see FC2 (section 10.4). Follow product maintenance (see section 13) and servicing (see section 11) instructions.

10.6 **Setting temperature for sensor operated mixers**

These products do not allow the user to select the desired blend temperature. We therefore recommend setting a blend temperature of 39 to 40°C rather than the normally applicable 41°C maximum associated with “user adjustable” products. This ensures comfort to more sensitive users.

11 **SERVICING - TYPE 3 SCHEME**

The need for servicing is normally identified as a result of the regular performance auditing.

Application	Maximum mixed water temperature during normal operation	Permitted maximum stabilised temperature recorded during site testing – excluding transient spikes
Washbasin	41°C *	43°C

Table 2 A guide to maximum temperature sets

* See section 10.6: setting temperature

11.1 **Frequency of regular servicing**

The purpose of servicing regularly is to monitor any changes in performance due to changes in either the system or the product. This may highlight the need to adjust either the supply system or the product. These products should be audited 6 to 8 weeks and again 12 to 15 weeks after commissioning. The results are to be compared against original commissioning settings. If the product passes the audit test three consecutive times (demonstrating good stability of system & product) then a 12 monthly servicing cycle may be adopted.

Otherwise, servicing checks should be carried out more frequently (E.g. every 4 months).

Follow the recommended auditing and maintenance procedures detailed in sections 10 & 13. During servicing, note the following:

- 1. Repeat the procedure of recording and checking supply temperatures. (The same type of measuring equipment should be used)
- 2. If the temperature has changed significantly from the previously recorded values, the following should be checked:
 - a. All in-line or integral valve strainers are clear of obstruction.
 - b. All in-line or integral check valves are clean and working properly to prevent backflow.
 - c. Any isolating valves are fully open.
 - d. The thermostat is free of debris
- 3. When satisfied with the mixed outlet temperatures re-record the temperatures.

12 **MAINTENANCE OF IN-LINE COMPONENTS**

In this example, (see figure 25) the isolator screw slot is shown in the vertical position. This indicates the valve is open. To close this valve, rotate the isolator screw by 90° into the horizontal position. By operating the product, this will drain down the water from the pipes below the service valve. Once the product has been isolated, this will permit maintenance staff to:

- 1. Check & clean the strainers by unscrewing the strainer cap.
- 2. Replace the in-line solenoid valves if necessary.
- 3. Completely remove the product from the panel if necessary.




Figure 25 In-line Service valve with strainer

13 MAINTENANCE

When installed as a TMV3 application it is a requirement that the commissioning and maintenance procedures, detailed under 10 & 13, be carried out.

13.1 Adjustment of the mix temperature:

- **Note: Cartridge is factory pre-set at $40 \pm 1^\circ\text{C}$ *.**
- Prise out the cover button, then use a 4mm Allen key to remove the screw.
- Lift off the lock shield.
- Remove both rotational stops from the spindle.
- Turn the spindle to achieve a $40 \pm 1^\circ\text{C}$ * mixed. (Clockwise to reduce and anti-clockwise to increase).
- Refit both stop rings against the anti-clockwise rotation stop face.

Note: 1. This is the normal maximum temperature range for the product and as such there is a wide zone of spindle movement that gives this mix temperature. For best performance you should refit the stop at the first point of anticlockwise rotation that achieves the desired setting.

2. If you are unable to achieve $40 \pm 1^\circ\text{C}$ * and you have the correct Δt 's it may be due to fine debris. **See section 13.2 Removal and inspection of cartridge.**

- Upon successful completion of the temperature adjustment, conduct the **Cold Water Isolation (CWI) test** (See section 10.5) to ensure product is working properly.
- Refit the lock shield and record the mix temperature.

* See section 10.6: setting temperature




Figure 20 Adjusting the pre-set temperature

13.2 Removal and inspection of cartridge

After checking that supply conditions are within the specified parameters (see table 1), if the fitting malfunctions or should the test results fail to fall within the specified limits consider replacing the cartridge with a new one. **See section 13.3 Important notes on debris.**

Isolate the fitting by rotating the integral isolating valves fully clockwise.

Remove the lock shield as described in section 13.1. Unscrew the cartridge from the body with a 36mm a/f deep socket. Inspect cartridge for damage.

Replace cartridge if necessary and reassemble cartridge into body

The replacement cartridge should be tightened to a torque of 15Nm. (To re-secure the cartridge we recommend the use of PermaBond A011 or equivalent applied to the thread of the cartridge)
Replace the lock shield and reinstate the supplies.

- **Redo the Cold Water Isolation (CWI) test** (See section 10.5).
- Once satisfied with the CWI test, re-check and if necessary, adjust the maximum mix temperature, see (See section 13.1).
- Record the mix temperature.




Figure 21 Exploded view showing sequential cartridge

Maintenance continued...

13.3 Important notes on debris

Although this product is protected by built-in strainers, debris can still find its way to the thermostat housing area. This can happen during servicing for example. Remove cartridge (see section 13.2) and carry out an inspection.

13.4 Thermostatic Cartridge Ageing

Following many years of normal service you may notice the following:

1. The need to carry out more frequent adjustment of mixed temperature.
2. The thermostatic element may not pass the CWI test.

These issues could be due to the ageing of the thermostat which loses some expansion capability over time.

These are the principle objectives of testing, as they serve to indicate to maintenance staff the declining performance capability of the thermostatic cartridge.

For this reason the audit testing flow chart highlights that 2nd Instance CWI test failure or 2nd instance mixed deviation even with stable 'as commissioned' supply conditions and correct inlet supply Δt 's, is potentially the first indication of the need to replace the cartridge.

13.5 Armitage Bioguard Outlet

Traditional "flow straightener" type outlets have recently been identified by extensive research as an area most likely to harbour bacteria. This product uses an Armitage Bioguard outlet which replaces this traditional flow straightener with a fully open copper-lined waterway. This greatly reduces the risk of bacteria build-up whilst the copper lining has natural anti-microbial properties.

Outlet is suitable for autoclaving.

In the interests of infection control and health hygiene, the Armitage Bioguard Outlet is a supplement to, not a substitute for, standard infection control practices. Continue to follow all current protocols, including those practices related to cleaning and disinfection of surfaces. Refer to HTM04-01 for more details.

Patent pending for Armitage Bioguard antibacterial outlet, application No: 10 2012 107 243.4

OUTLET FILTER: The Armitage Bioguard outlet can be removed (as described below) & replaced with a universal filter adaptor, see section 16. The adaptor will accept most filter types which are externally threaded M24x1

13.6 Maintenance cleaning

On a regular basis the outlet should be inspected and cleaned.

To unscrew and remove the outlet, use an adjustable spanner on the flats (20mm). To refit, hand tighten and then use the spanner until the outlet has bottomed in the bore. Take care not to over tighten.

In areas where lime scale build-up is prevalent this should be avoided by regular cleaning. If it should build up, it will have to be removed. An inhibited proprietary scale solvent can be used such a kettle descaling solvent but it is important to follow the manufacturer's guidelines. After descaling it is important to rinse the parts thoroughly in clean water. Clean carefully and do not use abrasive materials or scrapers


Note: Lime scale deposits should be removed prior to using any disinfection treatments.

Maintenance continued...

13.7 Hygiene flush (Automatic)

This hygiene flush is an important optional function of these products which can be enabled by the installer or maintenance staff.

The hygiene flush is used to combat periods of stagnation due to low usage of the product. The function activates the spout automatically if it hasn't been used for a set time period. This function ensures regular movement of water combating bio film growth and bacteria colonisation.




This product has a one-off flush function which allows the water to flow from the spout for 5mins (300 sec.). To activate, cover the sensor with a finger for 15 seconds, water runs continuously for 300 sec. (This can be done when the product is in normal operation mode).




Alternatively, the product can be set to automatically flush once every 24 hours. At the factory, this function is switched off, & would have to be activated if required. Run time is 15 sec. If activated at 2pm for example, flush will occur 24 hours later at 2pm next day (±30 minutes).

To activate this 24 hour flushing cycle, enter configuration mode by powering off & on, see details in section 9.

Once in the configuration menu, cover the sensor with a finger for 10 sec. There will be a first 2 sec confirmation flush at 5 sec & a second flush at 10 sec. Remove finger immediately, observe the sensor, a LED will flash once to indicate 24-hour flush is activated (ON)




To switch off the 24 hour flushing cycle, repeat this sequence, LED will flash twice to confirm ON.




Maintenance continued...

13.8 Solenoid valves




If water continues to flow when the tap should be off, and if the sensor is correctly ranged, then the solenoid valve may have debris lodged in the diaphragm pilot hole or on the valve seat:

- Locate the solenoid valve.
- Isolate the water supplies.
- Disconnect the solenoid valve cables.
- Remove the 3 screws holding the coil.
- Lift off the coil assembly.
- Locate the diaphragm (inside the valve body).
- Clean out the pilot hole(s) – use a thin gauge fuse wire (or similar).



If diaphragm is damaged it should be replaced.



- Ensure there is no debris on the diaphragm or the valve seat (under diaphragm).
- Re-assemble solenoid valve.
- Reconnect water supply, check there are no leaks.
- Reconnect the solenoid valve cables.
- Test the solenoid valve & ensure it is working correctly.

If the solenoid plunger becomes dislodged from its bore, **ensure it is refitted correctly. The end with the small black insert should face towards the diaphragm.**

Incorrect assembly will cause continual running.




Maintenance continued...


13.9 Spout removal

This mixer is fitted with a quick easily removable spout to assist with cleaning, disinfection by immersion or sterilisation by autoclaving.


Procedure assumes availability of a replacement spout. For both practical functional reasons along with environmental contamination reasons, the mixer should not be left without a spout in place.



1. Ensure the handle is in the off position.
To remove the spout: gently rotate the end of the spout anticlockwise by 90°.



2. The spout should now be in the horizontal position as shown.



3. Gently pull the spout away from the body as shown.

Quarantine this spout for cleaning protocols.

Ensure replacement spout complies with cleaning protocols.

To refit a spout, reverse this procedure.

Cleaning / disinfecting / sterilising the removed spout.

Physical **cleaning** is only necessary if evidence of solid deposits e.g. calcium or similar can be seen around the outlet.

Disinfection can be achieved by immersing in an appropriate bactericidal solution, using this method we would strongly recommend removal of the Armitage Bioguard outlet from the spout prior to immersion. For disinfection solution **see section 13.11.**

Sterilisation can be achieved by autoclaving for the desired period. Complete spout can be autoclaved (NB; the seals can withstand this process).

Additional spouts are available so during cleaning protocols an alternative spout can be fitted while the original is removed. This insures continuity of use of the mixer.

For additional spout part numbers, **see section 16.**



IMPORTANT:

Do not leave the mixer outlet open without a spout fitted.

13.10 Demounting mixer

Maintenance continued...

In response to the new requirements of HTM 04-01 Addendum, the designs of these mixers have been enhanced to permit easy demounting of the mixer from the inlets.

This updated design permits quick & easy removal of the mixer for cleaning, disinfection (as **section 13.9** notes) & maintenance purposes.


Prior to commencing this procedure, you should have available either a replacement mixer (without inlets) or a pair of protective cover caps. **See section 16.**

IMPORTANT: For sensor operated products, DO NOT isolate mains power supply.

Method for demounting mixers:

1. Isolate the hot and cold or water supplies using the integral isolation valves. **See section 14.**
2. Undo the 2 grub screws securing the mixer using a 3mm hexagon key. (Take care not to lose the screws).
3. Remove the mixer from the inlets, by gently pulling away as shown. Expect some trapped water to escape.
4. To ease remounting of the mixer lightly smear the O-rings of the inlet legs with WRAS or REG4 approved grease (e.g.: Klueber Unisilikon L250L). Wipe off any excess.
5. During cleaning protocols:
Fit a replacement mixer (without inlets) to ensure continuity of use. Alternatively fit cover caps to protect & seal the inlets.
6. To refit the mixer; reverse this procedure. Tighten screws securely
7. Follow the commissioning procedure to ensure the product is functioning correctly. See section 10.

Smear a small amount of approved silicone grease onto the O-rings fitted on the inlet legs. This will help to prevent damage to the O-rings during assembly. Use a WRAS or REG4 approved silicone grease (e.g.: Klueber Unisilikon L250L).



Disinfection by full immersion in an appropriate bactericidal solution is recommended for this assembly. Prior to immersion, the fitting should be clean and dismantled to a level that prevents air locking. In some cases it may be considered appropriate to dismantle the fitting prior to demounting.

The level of dismantling should be established as a result of practice and will be largely dependant upon the water quality and service life. As a minimum we recommend removal of the handle & thermostatic cartridge. All components can be immersed together unassembled.

Disinfected mixers should be promptly replaced or stored using an appropriate method until required. For disinfection solution **see section 13.11**




Take care to avoid damaging the inlet seals. Damage to these seals would compromise the insulate feature & affect the mixer's thermostatic performance. See section 18 for spare "demountable seal kit".

Demounting mixers continued

Inlet O-ring damage

If the front O-ring seals (as shown below) fitted on the inlet legs become damaged, then leaking water will cause pressure build-up inside the fitting & eventually force out an end cap.



If an end cap is forced out, replace the damaged inlet O-ring(s), then drain off any water from the cavity & refit the end cap.

If an end cap is forced out, or water drips from the end cap, these are indications of a damaged O-ring. Replace the seal as soon as possible, as the mixer's safe touch (thermal insulation) feature will be compromised.



IMPORTANT NOTE: END CAPS. The chromed end caps should not be removed. There are no serviceable parts within this cavity.


Inlet legs – removal

If one or both inlet legs are removed from the panel for maintenance or repair, then it is **important** to note the following:

ALIGNMENT

Prior to installation, both inlet legs must be securely fixed to the mixer body. Fit the complete assembly to the panel, then secure with the back-nut kit. Back nut torque 25Nm.

Note: **Do not** separate inlet legs & install them individually onto the panel, as alignment to mixer body will be lost. In this case, mixer body will not correctly locate onto the inlet legs & may damage the O-rings during installation.




Maintenance continued...

Protective cover caps

If a replacement mixer is not available, a pair of protective cover caps should be fitted to the inlets. For product code see section 16.

For both practical and functional reasons along with environmental contamination reasons, the inlets should not be left open.



Push the caps onto the inlets until they stop against the shoulder.

Take care not to damage the o-ring seals.

Secure the caps with grub screws as shown using a 3mm hexagonal key. Leave the hot & cold supplies isolated.

Cover caps should be disinfected / sterilised when necessary.



IMPORTANT:

Do not leave the mixer inlets open without a body or cover caps fitted.

13.11 Disinfection solution

As discussed in sections 13.9 & 13.10, for disinfection, we recommend parts be immersed in an appropriate bactericidal solution.

The frequency of such disinfection actions will be derived from regular sampling carried out under the regime of the Responsible Person (Water). We would not expect to need greater than 6 monthly frequencies, hopefully considerably less.

The need for excessive use of this procedure would be indicative of the need for some root cause analysis as there could be some system or behavioural problems that need addressing.

IMPORTANT ADMINISTRATION NOTE:

Where an audit log document (report or electronic record) is being kept for a mixer, consideration should be given to the mixer's traceability during the demounting & disinfecting process.


Avoid using disinfection solutions that contain ammonia. Note: ammonia can lead to stress corrosion cracking of the brass components inside the fitting.

13.12 Strainers

To ensure trouble free operation of the mixer, the integral inlet strainer elements should be checked and cleaned at a frequency in accordance with the commissioning and servicing guide.

1. Unscrew and remove the Chrome Panel Shrouds and pull the Chrome Sleeves forward off the inlet seals.
2. Isolate both inlets by screwing the isolation valves down fully using a 5mm hexagon key in the clockwise direction. (Operate lever to confirm water supplies are closed off).
3. Undo the 2 grub screws securing the mixer using a 3mm hexagon key. (Take care not to lose the screws).
4. Remove the mixer from the inlets, by gently pulling forwards. Expect some trapped water to escape.
5. Unscrew and remove the strainers from the underside of the Inlets using a 5mm hexagon key
6. The strainers should be inspected and washed with clean water and can be Autoclaved or replaced as necessary
7. Before re-assembling the strainers we recommend flushing the inlets with our purging and water sampling kit - A6899NU (not included)
8. When refitting the strainers, **DO NOT OVER TIGHTEN**, observe torque setting shown below.

Removal and flushing procedure **SEE section 6.1**



14 INTEGRAL ISOLATION VALVES


The integral isolation valves facilitate a number of activities:

- Servicing the thermostatic cartridge
- Audit Cold Water Isolation (CWI) test
- Demounting the mixer from its inlets

To isolate the mixers, proceed as follows:

1. Unscrew the wall shrouds and slide forward
2. Isolate both inlets by screwing isolation valves down fully using a 5mm Allen key in the clockwise direction
3. Reverse procedure to restore the water supplies and refit the shrouds

INTEGRAL ISOLATION VALVES continued...



15 COMBINED CHECK VALVE REGULATORS


To prevent back siphonage of water to the supply pipes, check valve regulators (CV/FR's) are fitted inside the inlet tails at the front of the panel.

The CV/FR's can be replaced, but **MUST NOT BE REMOVED**.

Replacement Instructions

First remove the Ø12mm circlip.

The CV/FR can now be removed using long nose pliers; however there is a high probability of damage during removal.




IMPORTANT:

The CV/FR's can be replaced

The pink CV/FR must be fitted to the cold water inlet (Right side of the mixer when viewed from the front)


The yellow CV/FR must be fitted to the hot water inlet (Left side of the mixer when viewed from the front)

16 MARKWIK 21+ ACCESSORIES




A6252AA

Panel mount spout complete.
Short version with 100mm reach.
Fitted with Armitage Bioguard outlet
& o-rings at the mixer coupling end.
See section 13.9



A6250AA

Panel mount spout complete.
With normal 135mm reach.
Fitted with Armitage Bioguard outlet
& o-rings at the mixer coupling end.
See section 13.10




A6255AA

Cover caps kit.
To protect & seal the inlets legs when
a mixer has been demounted & removed.
See section 13.10




A6256AA

Universal filter adaptor.
Replaces the Armitage Bioguard outlet
to permit attachment of an outlet filter.
Threaded M24x1 (internal).



A6899NU

Panel Flushing set
See section 6.1



A6898NU

Deck Flushing set



Extension cables

If the installer wishes to position the PSU in the ceiling area for example,
then cable extensions are available:

SENSOR & SOLENOID EXTENSION LEADS: A963703NU: (Pair, 2M long).
Containing grey/black power lead for sensor & black/red lead for solenoid.



CABLES SHOULD NOT BE CUT (OR SHORTENED), AS THIS WILL INVALIDATE WARRANTY.

For more information on accessories contact our customer care.

17 SPARE PARTS - ELECTRICAL





Figure 28 Behind Panel Spares

Ref.	Description	Part No.
1	SV link cable 500 long (red & black)	A962477NU
2	Inline service valve with filter only.	E960086NU
3	SV coupler kit (pair)	A962499NU
4	Solenoid valve with seals	A962478NU
5	PCB only with transformer	A960159NU
6	Velcro pad kit	A860704NU
7	PSU Complete	A962881NU
8	Strainer & O-ring kit (pair)	A861284NU

18 SPARE PARTS




Spare parts List - mixer

Ref.	Description	Part No.
1	Cap	--
2	Handle screw	A961950NU
3	Handle SET	E960615AA
4	Sensor IR complete with wire	A861709NU
5A	Sequential, thermostatic cartridge	A861165NU
5B	O - ring + stainer set thermostatic cartridge	A861166NU
5C	Splined cap & splined locking ring -cartridge	A861310NU
5D	Thermostatic cartridge –one stop ring - box of 10 pieces	A861290NU
6	Body	--
7	Outlet	F960847AA
8	Screw (available in 30 set)	--
9	Escutcheon + O-ring	A962346AA
10	Side sleeve cpl.	A861160NU
11	O - ring Ø 11 x 2	A960942NU
12	O - ring Ø 13 x 2	A861101NU
13	Sleeve	--
14	Threaded nut M18x1,5	--
15	Cap w. o - ring Ø 30 x 2	A861124NU
16A	Inlet Set, cold water	A861347AA
16B	Inlet Set, hot water	A861348AA
17	O-ring 17 x 2.5	A963143NU
18	O - ring Ø 24 x 2	A961809NU
19	Inlet insulator	--
20	Inlet Sleeve	--
21	Circlip (Pack contains 4x parts)	A861346NU
22a	Combined CV&FR Ø10mm, cold water (pink) right side	A861215NU
22b	Combined CV&FR Ø10mm, hot water (yellow) left side	A861216NU
23	O - ring Ø 12,42 x 1,78	A961332NU
24	Isolation plug cpl. (2 sets)	A861329NU
25	O-ring dia 8.1 x 1.6 (single) - (available within item 16)	A962345NU
26	Wall plate	E960633NU
27	O-ring Ø51 x 2.4	E960632NU
28	Slip washer Ø60 x Ø25 x 2	E960631NU
29	Backnut	E960112NU
30	Demountable seal kit with grub screws, o-rings & hex key	A861162NU
31	O-ring Ø15 x 2.5	F961003NU
32	Brass flow straightener (star shape insert - optional)	S961044NU
33	Timed flow proximity sensor & housing	E960620AA
34	Strainer	A861172NU
35	Check valve DW15 (Pair)	A962594NU




For more information on spare parts why not visit our spare website:
www.fastpart-spares.co.uk
 or contact customer care

19 CLEANING CHROME SURFACES



Whilst cleaning this product, the water flow from the spout can be temporarily switched off. To activate, cover the sensor with a finger for 10 seconds, this will switch off the water for 60 sec. (This can be done when the product is in normal operation mode).



When cleaning chromed products use only a mild detergent, rinse & wipe dry with a soft cloth. Ideally clean after each use to maintain appearance.

Never use abrasive, scouring powders or scrapers. Never use cleaning agents containing alcohol, ammonia, hydrochloric acid, sulphuric acid, nitric acid, phosphoric acid or organic solvents. Use of incorrect cleaning products / methods may result in chrome damage which is not covered by the manufacturer's guarantee.



For more information about our products & spares visit our websites: www.idealstandard.co.uk

AFTER SALES NON RESIDENTIAL HELPLINE

0870 122 8822

AFTER SALES NON RESIDENTIAL FAX

0870 122 8282

E-MAIL

aftersalesnonresidential@idealstandard.com


0924 / A 868 249R3

Armitage Shanks pursues a policy of continuing improvements in design & performance of its products. This right is therefore reserved to vary specification without notice. Partial or total reproduction or copying of this manual without our permission is prohibited. Every effort has been made to ensure the accuracy of its contents. However, if you discover any errors, please contact us. The manufacturer shall not be held liable for consequences arising from use of the product. The drawings & diagrams contained in this manual are to be considered approximate & are provided for information only.

Armitage Shanks is a division of Ideal Standard (UK) Ltd



Waste electrical & electronic equipment should be disposed of appropriately according to local regulations.



Ideal Standard (UK) Ltd.
The Bathroom Works
National Avenue
Hull HU5 4HS
England



Ideal Standard International NV
Corporate Village - Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium



<https://www.idealstandard.com>