V3IS00385-010

Vemer S.n.A



I - 32032 Feltre (BL) • Via Camp Lonc, 16 Tel +39 0439 80638 • Fax +39 0439 80619

e-mail: info@vemer.it - web site: www.vemer.it

Mod. ENERGY-230R TAi

CE



Connection diagrams





Accuracy





User Manual
ACTIVE ENERGY METER
Read all the instructions carefully

Static meter in standard dimensions 72x72 mm to read active energy consumption in single-phase 230V systems.

SAFETY WARNINGS

- To guarantee correct installation, proceed as follows: 1) The appliance should be installed by a competent operator 2) The appliance should be installed in a panel in such a way as to
- guarantee that the terminals are inaccessible after fitting 3) A protection device against over-currents should be installed in the electrical system, upstream of the energy meter
- Connect the instrument as shown in the alongside diagrams
- 5) Before touching the connector terminals make sure that the wires to be connected or already connected to the instrument are not live 6) Touch the dip-switches only when the instrument is not powered 7) Do not power or connect the instrument if any part of it is damaged
- M . 1.1 . ..

Coae	Model	Description
VE012100	ENERGY-230R TAi	Single-phase energy meter

TECHNICAL SPECIFICATIONS

- Power supply voltage: 230V CA (-15%/+10%) 50/60Hz
- Input current: $I_n = 5A$; $I_{MAX} = 6A$ Minimum start-up current: 15mA
- .
- Accuracy: class 2 to standards EN 62053-21 Maximum power consumption: voltage circuits < 2,5VA
- current circuits < 2,5VA
- Galvanically isolated amperometric input . Amperometric connection by AT x/5A
- . Selectable transformation ratios (for AT x/5 A): 5-10-25-50-75-100-125-150-200-250-300-400-500-600-800-1000/5
 - Operating temperature: -10 ÷ +45 °C
- Relative humidity: 10% ÷ 90% non condensing
- . Storage temperature: -20 ÷ +60 °C
- Signaling leds: green = power on
 - red = flashing at 1/16kWh
- Optoinsulated pulse output for energy consumption remote-monitoring (1 kWh/pulse)
 - Pulse specifications: duration = $100 \text{ ms} \pm 15\%$ voltage = $9 \div 24V \text{ CC} (\pm 10\%)$
 - switchable output current 20mA max
 - Protection degree: IP20
- Enclosure: standard dimensions 72x72mm

INSTRUMENT DESCRIPTION

- (1) 7-digit mechanical counter: resolution 1 kWh
- 2
- Green warning light: lights up to indicate power on Red warning light: every flash corresponds to an energy count of 1/16 kWh 3
- Dip-switch 1-2-3-4 for AT setting. Dip-switch 5-6 not used 4

GUIDE TO INSTALLATION

- 1) Before installing the instrument, select the transformation ratio required. Use an x/5A outer AT with a transformation ratio from among those set out in the description box. The AT secondaries may be connected to earth.
- The instrument should be connected as shown in the connection diagrams, in 2)accordance with the AT energy directions.
- 3) If the error is to fall within the class limits of the instrument, it is necessary to use the current transformer in its linear operating field. See the precision box:
 - Maximum measurement error in accordance with EN 62053-21 for class 2 meters with $\cos \phi = 0.5$ inductive **(A)**;
 - Maximum measurement error in accordance with EN 62053-21 for class 2
- meters with $\cos \phi = 1$ and voltage and frequency reference conditions (B). 4) If the instrument is active, the power should be switched off to change the AT ratio.

REFERENCE STANDARDS

Conformity to the EU directives: 73/23/CEE modified by 93/68/CEE (Low Voltage) 89/336/CEE modified by 92/31/CEE and 93/68/CEE (E.M.C.) is declared with reference to the following harmonised standard: EN 61010-1, EN 61000-6-2, EN 61000-6-3, EN 62053-21 and EN 62052-11