

Maintaining backup battery systems for maximum usage and reliability

Application Note

Standby battery backup systems play a critical role in keeping essential operations functional in the event of a utility outage.

Facilities like data centers, hospitals, airports, utilities, oil and gas facilities, and railways can't operate without 100% backup power reliability. Even standard commercial and manufacturing facilities have backup power systems for their emergency systems, alarms and controls, emergency lighting, steam and fire control systems.

Most backup power systems use an uninterruptable power supply (UPS) and a string of batteries. The UPS backs up the digital control system (DCS) to keep control of plant operations until systems can be safely shut down or until the auxiliary generator kicks on.

Although most batteries used in modern day UPS systems are "maintenance free" they are still susceptible to deterioration from corrosion, internal shorts, sulphation, dry-out and seal failure. This article outlines best practices for keeping these "battery banks" at optimum performance, so that if an outage does occur, the backup is ready.

Top two indicators of battery health

One: Internal battery resistance

Internal resistance is a life-span test, not a capacity test. Battery resistance stays relatively flat up until the end of life draws near. At that point, internal resistance

increases and battery capacity decreases. Measuring and tracking this value helps identify when a battery needs replacing.

Only use a specialized battery tester designed to measure battery resistance while the battery is in service. Read the voltage drop on the load current (conductance) or the AC impedance. Both results will be in ohmic values.

A single ohmic measurement is of little value without context. Best practice requires measuring ohmic values over months and years, each time comparing them to previous values on record to create a base line.

Two: Discharge testing

Discharge testing is the ultimate way to discover the true available capacity of a battery but can be complicated to perform. In discharge testing, a battery is connected to a load and discharged over a specified period of time. During this test period, current is regulated and a constant known current is drawn while voltage is measured periodically. Details of the discharge current, the specified time period for discharge testing, and the capacity of the battery in ampere hours can be calculated and compared to the manufacturers' specification. For example a 12V 100 amp hour battery may require a discharge current of 12A for an eight hour period. A 12V battery would be considered to be discharged when the terminal voltage is 10.5V.

Batteries cannot support critical loads during and immediately after a discharge test. Transfer critical loads to a different battery bank until well

after the test is complete and then re-connect a temporary comparably-sized load to the batteries under test. In addition, before conducting the test, prepare a cooling system to compensate for a rise in ambient temperature. When large batteries discharge, they release a significant amount of energy expended as heat.

Top 5 causes of battery failure

- 1 Loose terminals and inter-cell connections
- 2 Aging
- 3 Over-charging and over-discharging
- 4 Thermal runaway¹
- 5 Ripple

Weakest link

When one battery in a string fails, the entire string

- goes offline
- shortens lifespan²

Worst case

A battery with a high level of impedance can overheat and ignite or explode during discharge. Voltage measurements alone will not flag this danger.

¹ The main cause of battery failure is heat. For every 8 °C (15 °F) increase in average temperature battery life is cut in half.

² A single bad battery raises the charge voltage of adjacent batteries, due to charger settings, affecting the usable life of the entire string

RECOMMENDED battery tests and schedule

The Institute of Electronic and Electrical Engineers (IEEE) is the primary source of standard practices for battery maintenance. Over the life of the battery The IEEE recommends performing a combination of tests on a periodic basis.

The IEEE also recommends the following schedule for discharge testing:

- An acceptance test made at the manufacturer’s factory or upon initial installation
- Periodic discharge testing—at an interval not greater than 25 % of the expected service life, or two years, whichever is less
- Annual discharge testing—when any battery has reached 85 % of the expected service life or dropped >10 % from capacity

Since scheduling full scale discharge testing can be difficult, good regular maintenance is extremely important. By operating the battery according to manufacturer charging requirements and following the IEEE recommendations for battery testing, it should be possible to maximize the life of the battery system.

	Voltage and current			Temperature		Ohmic		Ripple
Items	Overall float voltage measured at the battery terminals	Charger output current and voltage	DC float current (per string)	Ambient temperature	Temperature of the negative terminal of each cell	Cell/unit internal ohmic values	Cell-to-cell and terminal connection detail resistance of entire battery	AC ripple current and/or voltage imposed on the battery
Monthly	•	•	•	•				
Quarterly	•	•	•	•	•	•		
Yearly and Initial	•	•	•	•	•	•	•	•

Figure 1: Inspections recommended by IEEE 1188 standard ‘Recommended Practice for Maintenance, Testing, and Replacement of Valve-Regulated Lead-Acid (VRLA) Batteries for Stationary Applications’



Using the Fluke BT52X to measure impedance, for the quarterly cell/unit internal ohmic value test.

Key indicators of battery failure

Healthy batteries should maintain a capacity above 90% of the manufacturer's rating; most manufacturers recommend replacing the battery if it falls below 80%. When conducting battery tests, look for these indicators of failure:

- Drop in capacity of more than 10% compared to the baseline or previous measurement
- 20% or more increase in resistance compared to baseline or previous
- Sustained high temperatures, compared to baseline and manufacturer's specs
- Degradation in plate condition

How to conduct standard battery tests

It is important to make sure you are wearing the proper personal protective equipment (PPE) before conducting the following tests.

Float voltage

1. Measure the individual cell voltage or string using a digital multimeter or battery analyzer such as the Fluke 500 Series Battery Analyzers on a monthly basis.

Charger output

1. Measure the charger output voltage at the charger output terminals using a digital multimeter or battery analyzer such as the Fluke 500 Series Battery Analyzers on a monthly basis.
2. Observe the output current shown on the charger current meter or use an appropriate dc current clampmeter such as an Amprobe LH41A. Measure monthly.

DC float current

1. Refer to manufacturers specifications for approximate values for expected float currents
2. Use an appropriate dc current clampmeter such as an Amprobe LH41A to measure expected float current on a monthly basis.

Internal ohmic values

1. Use a battery analyzer such as the BT500 series to measure the individual battery ohmic values on a quarterly basis.
2. Establish reference values and maintain in the battery database. The 500 Fluke Series Battery Analyzer family comes with a PC Battery management software and report generator to help you maintain your database.



Measuring ohmic values in sequence mode

Common battery terms

Capacity test: a discharge of a battery at a constant current or a constant power to a specified voltage.

Float voltage: the voltage at which the battery is held by the charging system to compensate for the natural discharge of the connected batteries.

Float current: the current that flows while the battery is held at the float voltage.

Internal Ohmic values: the internal resistance of the battery (a characteristic of every battery).


Discharge testing: the battery is connected to a load until the battery voltage falls below a defined preset limit.

AC ripple current: residual ac on the rectified voltage in dc charging and inverter circuits.

For complete specifications, visit www.Fluke.com

Fluke 500 Series Battery Analyzers

The new Fluke 500 Series Battery Analyzers were designed from the ground up to match IEEE recommendations for maintenance, troubleshooting and performance testing of individual stationary batteries and battery banks used in critical battery back-up applications.



Key features

- **Battery voltage**—Measures battery voltage during internal resistance tests.
- **Discharge volts**—Collects the voltage of each battery multiple times at a user-defined interval during a discharge or load test. Users can calculate the time a battery takes to drop to the cut-off voltage and use this time to determine the capacity loss of the battery.
- **Ripple voltage test**—Allows users to test ac components in dc charging circuits. Residual ac on the rectified voltage in dc charging and inverter circuits is a root cause of battery deterioration.
- **Meter and sequence modes**—Meter mode allows you to read and save a measurement or time sequence, during a quick test or troubleshooting. Use Sequence mode for multiple power systems and battery strings. Before a task starts, configure a profile for the task for data management and report generation.
- **Threshold and warning**—Configure a maximum of 10 sets of thresholds and receive a Pass/ Warning/ Fail indication after each measurement.
- **AutoHold**—AutoHold captures readings that remain stable for 1 second and then releases the reading when a new measurement starts.
- **AutoSave**—Automatically saves AutoHold captured readings to internal memory.
- **Battery management software**—for importing, storing, comparing, trending and charting data and meaningfully displaying that information in reports.
- **Highest safety rating in the industry**—CAT III 600 V, 1000 V dc max. rated for safe measurements all around the battery power supply equipment

Fluke. *Keeping your world up and running.*®

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

Fluke Europe B.V.
PO Box 1186, 5602 BD
Eindhoven, The Netherlands

For more information call:
In the U.S.A. (800) 443-5853 or
Fax (425) 446-5116
In Europe/M-East/Africa +31 (0) 40 2675 200 or
Fax +31 (0) 40 2675 222
In Canada (800)-36-FLUKE or
Fax (905) 890-6866
From other countries +1 (425) 446-5500 or
Fax +1 (425) 446-5116
Web access: <http://www.fluke.com>

©2014 Fluke Corporation.
Specifications subject to change without notice.
Printed in U.S.A. 10/2014 6004018A_EN

Modification of this document is not permitted without written permission from Fluke Corporation.