



BOWDENS

OMEGA 4



ADVANCED DIRECTIONAL FAULT PASSAGE INDICATOR (FPI) FOR UNDERGROUND CABLE NETWORKS - Earth Fault and Overcurrent FPI with 4G Communications Option.

enquiries@springltd.co



1.0 Overview

Bowdens have been influential in the design of the Electronic Earth Fault Indicator (EEFI) since the company first introduced this type of indicator in 1991. It now has a wide and proven range of earth fault indicators for fault indication on 11kV cable networks. The Omega 4 fault indicator is an exciting development from this highly successful range of instruments to meet the demand of low cost instrumentation with minimal 'life time' costs.

The Omega 4 Fault Path Indicator (FPI) is a modular designed instrument that provides many options to the user depending on the required features. From one basic earth fault FPI, options can be added to make a full overcurrent and earth fault indicator and/or a directional FPI with integral GSM/GPRS or 4G communication and/or Modbus over RS485 with individual phase load monitoring and historic log. The Omega 4 is simply an earth fault indicator that will provide a clear visual indication of the passage of fault current and assist engineers to locate a faulted section of network on an Open Ring circuit. The faulted section of cable lies between the last fault indicator to Alarm and the first not to Alarm.

Omega 4 is designed to complement network automation and management giving greater visibility of network faults, enabling the fault engineer to isolate a fault intelligently, without the need for fault switching to locate a fault, with the inherent customer interruptions and excessive stress on plant and equipment.

The Omega 4 module consists of a polycarbonate enclosure, which has a seal rating of IP65 giving a high level of environmental protection. The front of the enclosure displays two high intensity alarm LEDs for earth fault (EF) and overcurrent (OC) indication. There are also four menu control buttons that enable the end user access to all FPI settings, including test and reset functions. An LCD display gives a visual display of all functions and data.

The Omega 4 can be configured either as a single channel Earth Fault indicator (EFI), requiring one core balanced Current Transformer (C/T) to drive the input, or as a 3 channel overcurrent and earth fault indicator (OC/EFI), requiring three single phase C/Ts.

The Omega 4 Earth Fault Indicator with a Core Balance C/T can be fitted around the MV power cable externally to the MV switch cable box or internally within the cable box, so long as appropriate station earthing arrangements apply (See Drawing 1).

The Omega 4 has the option of providing Modbus communication over RS485 to integrate with local RMU systems if required.

Two sets of isolated volt free relay contacts are provided for alarm indication. The relays can provide latched or pulsed indication. The unit also provides remote indication and remote reset functions as standard.

The Omega 4 is tested beyond normal IEC levels to ensure reliable operation in the hostile electromagnetic and electrostatic environment in which it operates. This includes testing of the communications functions, which must also perform within the same environment.


2.0 Operation

The Omega 4 can be programmed for many functions, via an LCD display and standard four button pad. Access to the programming feature is by PIN Code security, which will allow the unit to be programmed by an engineer in the office. However, the operating parameters can be pre-set at manufacture through an agreed profile which will contain all the settings required.


2.1 Omega 4 Interface

There are two types of data presented by the unit. Live read only data and settings. The live data is displayed after power on. The settings can be programmed by pressing and holding left and up, as indicated on the label. The right button can be used to reset an alarm, either manual test or real fault. Press and hold the right button for 5 seconds to perform the reset.

2.1.0 Startup and Live Data




The Omega 4 has an auto sleep feature to preserve power and prevent burn in on the interface LCD, to wake up the device press any of the 4 buttons.




On initial start up the display will show the live data, use the up and down buttons to scroll through the rest of the items.

For a full list please see section 2.1.2

2.1.1 Settings




To access the settings press and hold left and up for 5 seconds.



The settings are protected with a PIN code, use up and down to increment / decrement each digit and right to change digit to the correct PIN. The default PIN code is 0014. When the correct PIN is entered, press back to access the settings.

The settings are organised in a menu tree, to navigate the menu, use the up and down buttons to select a menu item, then press right to go in to that menu item. This will either follow the tree down into a child menu, or allow editing the setting.


The left button will return back up the tree, either from a child menu, to parent menu or from editing a setting back to the menu. For a full list of settings see section 2.1.3.



Up / down selects the menu item, the arrow on the right hand side indicates which menu item is currently selected.



Press right to enter menu item. If this enters a child menu, this will follow the same navigation patterns as above.



To change the value of a setting use up / down. Left will return to the parent menu.

2.1.2 Live Data

Menu	Minimum	Maximum	Description
Live			Header
Mode			Mode of device, either EF, OC, EF OC, LV EF, LV OC, LV EF OC
Battery	bad	good	Indication of state of charge of battery
Temp	-25°C	70°C	Temperature of unit
Time	00:00	23:59	System time
Date	01/01/1970	01/01/2106	System date
Phase 1	0A	1000A	Phase 1 current (not shown if mode is not OC)
Phase 2	0A	1000A	Phase 2 current (not shown if mode is not OC)
Phase 3	0A	1000A	Phase 3 current (not shown if mode is not OC)
Earth	0A	250A	Earth current (not shown if mode is not EF)
LV freq	0Hz	65Hz	Frequency of LV (not shown when mode is not LV)
Last Fault			Header
Type			Type of fault, either EF, OC or EF + OC
Time	00:00	23:59	Time of fault
Date	01/01/1970	01/01/2016	Date of fault
Phase 1	0A	1000A	Phase fault current (not shown if fault type is not OC) ¹
Phase 2	0A	1000A	Phase fault current (not shown if fault type is not OC) ¹
Phase 3	0A	1000A	Phase fault current (not shown if fault type is not OC) ¹
Earth	0A	250A	Earth fault current (not shown if fault type is not EF) ¹
P1 angle	0	359	Phase 1 fault angle, NA if not available (not shown if mode is not LV) ²
P2 angle	0	359	Phase 2 fault angle, NA if not available (not shown if mode is not LV) ²
P3 angle	0	359	Phase 2 fault angle, NA if not available (not shown if mode is not LV) ²
Earth angle	0	359	Earth fault angle, NA if not available (not shown if mode is not LV) ²

Last fault data will be updated on each detected fault and remain in memory even after power cycling, until the next fault. Because the visible items are dynamic the menu will be reset to the top when a new fault is detected.

```
Phase 2    199A*
Phase 3    23A
```

¹ A '*' at the end of the line indicates the current went over threshold.

```
P2 angle   189*
P3 angle   243
```

² A '*' at the end of the line indicates the angle was on a phase that was over threshold.

2.1.3 Settings

Menu	Default	Min	Max	Options	Description
Test alarm	Idle			idle / in alarm	Set to “in alarm” to trigger a manual test. This tests the FPI alarm functions including the alarm LEDs, fault LCD indication, alarm relay activation and test alarm communication (if modem is fitted). To RESET press and hold the right button.
Mode	EF			EF, OC, EF OC, LV EF, LV OC, LV EF OC	Select mode of FPI EF – Earth Fault only OC – Over Current only EF OC – Earth Fault and Over Current LV EF – Earth Fault with angle to Low Voltage LV OC – Over Current with angle to Low Voltage LV EF OC – Earth Fault and Over Current with angle to Low Voltage
CT ratio	500:1			40:1, 60:1, 500:1, 1000:1	Set to fitted CT ratio
Bias fitted	fitted			fitted, not fitted	Some CT ratios require a bias resistor link, the display will flash a warning. Fit the resistor and set this menu accordingly.
EF trip	50A	20A	120A	20A, 30A, 40A, 50A, 60A, 70A, 80A, 90A, 100A, 110A, 120A	Fault current on the cable network generates a proportional voltage at the CT secondary output, which if above a pre-set threshold will trigger the FPI. Once the trip delay (EF delay) is over, the FPI will respond to any current above the pre-set Earth fault trip threshold as an alarm.
EF delay	50ms	20ms	200ms	20ms, 30ms, 40ms, 50ms, 60ms, 70ms, 80ms, 90ms, 100ms, 120ms, 140ms, 160ms, 180ms, 200ms	Once a fault is detected it starts a trip delay during which any alarms are suppressed. This is to allow magnetising inrush or capacitive currents on the HV network to dissipate. Once this trip delay has elapsed the FPI will alarm if the fault is over the earth fault trip threshold current.

Menu	Default	Min	Max	Options	Description
OC trip	625A	125A	750A	125A, 250A, 375A, 500A, 625A, 750A	Fault current on the cable network generates a proportional voltage at the CT secondary output, which if above a pre-set threshold will trigger the FPI. Once the trip delay (OC delay) is over, the FPI will respond to any current above the pre-set phase trip threshold as an alarm.
OC delay				20ms, 30ms, 40ms, 50ms, 60ms, 70ms, 80ms, 90ms, 100ms, 120ms, 140ms, 160ms, 180ms, 200ms	Once a fault is detected it starts a trip delay during which any alarms are suppressed. This is to allow magnetising inrush or capacitive currents on the HV network to dissipate. Once this trip delay has elapsed the FPI will alarm if the fault is over the OC trip threshold current.
Relay mode	latch			latch, pulse, multi	Sets the relay mode. In latch mode the relay will remain on after the fault is detected until a reset condition is met. In pulse mode, the relay will close for 10 seconds once when a fault is detected. In multi mode the relay will close for 10 seconds for every fault detected, including during an existing fault.
Reset time				1hr, 2hrs, 3hrs, 4hrs, 5hrs, 6hrs, 7hrs, 8hrs, 9hrs, 10hrs, 11hrs, 12hrs	The FPI will remain in the alarm state for the number of hours to which the reset time is set, unless it receives a reset from other means such as from the front panel reset button, a remote reset or an LV reset.
Reset LV	on			on, off	If LV reset is set to on, it will reset when the local LV source is re-energised.
Reset LV time	15	15	120		Number of seconds LV signal must be present to perform a reset. Only valid if Reset LV = on
Time		00:00	23:59		Set the current time
Date		01/01/1970	01/01/2106		Set the current date

2.1.4 System Messages

```
SYSTEM:
Reset timeout
```

The system has reset after a fault because the timeout has been reached

```
SYSTEM:
Reset user
```

The system has reset after a fault because the user has held the reset button

```
SYSTEM:
Reset LV
```

The system has reset after a fault because the LV power has been restored

```
SYSTEM:
Reset remote
```

The system has reset after a fault because the remote reset was triggered

```
ERROR:
Fit bias link
```

The CT ratio selected requires the bias resistor link to be fitted. Fit the link and change the “Bias fitted” setting to “fitted”

```
ERROR:
Remove bias link
```

The CT ratio selected requires the bias resistor link to NOT be fitted. Remove the link and change the “Bias fitted” setting to “not fitted”

```
ERROR:
EF<100 if CT=60
```

If CT ratio is equal to 60:1 the earth fault threshold MUST be below 100

```
ERROR:
EF<70 if CT=40
```

If CT ratio is equal to 40:1 the earth fault threshold MUST be below 70

```
ERROR:
EF ONLY CT!=500
```

Over current detection can only be performed with a CT ratio of 500:1, make sure the correct CT is used and change “CT ratio” to 500

2.2 Software Operation

2.2.1 Alert State

In the 'Alert' state the unit is ready and waiting to capture the next earth fault. There is no visual indication. The 'FAULT' LEDs are de-energised. The Alarm Relay contacts are in the 'no fault' position. The digital flag indicator will be off.

2.2.2 Alarm State

In the 'Alarm' state the unit has captured an earth or over current fault. There are two high intensity FAULT LEDs, marked EF for Earth Fault and OC for Over Current fault, that will give short flashes alternately every 4 - 5 seconds. The digital flag indicator will flash the fault warning triangle. The Alarm Relay contacts will change to the fault / alarm position and if the modem is fitted an update will be sent over the mobile network. The unit is now in power-save mode with the LED's and warning triangle flashing on until it receives one of the reset conditions. This could be either the built in reset timer (with selectable time), a remote reset input 6-35Vac/dc, an LV reset or manual operation of the RESET button. Any one of these resets will return the unit to the 'Alert' state, and will initiate another update via the modem.

2.2.3 Alarm Manual Test

Select the "Test alarm" function using the menu buttons on the front face of Omega 4, the FPI will enter alarm state as outlined in 2.2.2. The menu item will show "in alarm". Press and hold the Enter Button to RESET or wait for timed reset to return to idle state.

2.2.4 Earth Fault Detection

The Earth Fault threshold is set using the menu system.

Once the unit has powered up and has entered the 'Alert' state it is ready to capture out of balance faults. EARTH FAULTS: When an earth fault occurs the out of balance fault current will be detected by the Current Transformer, so long as the circuit breaker or RMU earth has been brought back through the C/T to allow a positive flow of fault current through the C/T (Drawing 1). Omega 4 uses a current/time graph to detect faults, which have to be above the threshold for a set number of cycles (EF Trip delay) to identify the disturbance as fault current, rather than a spike or surge that could be caused by magnetizing or capacitive currents. The EF trip delay and Earth Fault trip threshold are set using the Omega 4 menu system.

2.2.5 Earth Fault C/T Connection

Omega 4 will operate from either the Bowdens Band Sensor C/T (120mm id.) (see Drawing 3) or a Resin Cast Core Balance C/T (90mm id or similar). It can be configured at build time to operate from most common ratios of Core Balance C/T types. The C/T must detect the out of balance when installed around a three phase cable, either externally on the incoming cable to the RMU or circuit breaker, or internally in the cable termination box. In all cases it is important to observe the correct configuration of the station earth to ensure an out of balance can be seen during fault (see Drawing 1, Fig 6.1). Omega 4 may also be connected to the

three bushing C/Ts in an RMU or Circuit breaker. In this configuration the C/T outputs can be commoned to give a single input to the Omega 4 FPI.

2.2.6 Overcurrent & Earth Fault C/T detection

The Overcurrent threshold is set using the menu system. Overcurrent requires a C/T to be fitted to each phase of the supply. Normally for UK 11kV connections this means three C/Ts one each for Red, Yellow and Blue phases. A C/T monitors each individual phase to identify a current in any phase that is above the pre-set threshold for a given number of cycles, as well as the three phase currents being summated to give Earth fault current out of balance.

Omega 4 uses a current/time graph to detect faults, which have to be above the threshold for a set number of cycles (Phase Trip delay) to identify the disturbance as fault current, rather than a spike or surge that could be caused by magnetizing or capacitive currents. The Phase Trip delay and Phase Fault trip threshold are set using the Omega 4 menu. In this way the Omega 4 can detect and provide indications for both Earth Fault and Overcurrent fault conditions.

2.2.7 Overcurrent C/T Connection

OVERCURRENT FAULTS: When an overcurrent fault occurs the overcurrent will be detected by one of three Current Transformers connected (Drawing 1, Fig 6.4 and 6.5).

2.2.8 Directional Indication

The Omega 4 incorporates a Digital Flag Indicator. This has two functions:

1. It provides high visibility, high contrast visual indication that a fault has been detected with a warning triangle.
2. It provides a visual indication of the fault direction, LEFT or RIGHT (see figure below).



The Omega 4 calculates the fault direction by taking either VPIS or LV supply voltage as a reference. It is important that this voltage is connected to the LV connector.

On either side of the fault the fault current will be in opposite directions. Hence all of the FPIs downstream of the fault will indicate in one direction, whilst all FPIs upstream of the fault will indicate in the opposite direction. These directions are shown on the front of the Omega 4 but also transmitted as a remote indication and over the GSM modem.

When no fault current is detected then the warning triangle will not be shown.

When no fault direction is detectable, the direction arrows will not display and (if a fault is detected) only the warning triangle will display.

NOTE:

1. All Omega 4 units must be connected to the SAME VPIS or LV reference.

2. All C/Ts must be mounted with the same orientation to ensure correct directional indication along the network (See Drawing 2).
3. All C/T terminations to the C/T screw terminals in the Omega 4 must be connected with the same polarity. See Drawing 3.

2.2.9 Reset Conditions

There are four ways to reset the Omega 4:


1. LV reset: the Omega 4 will reset when the local LV source is re-energised. The LEDs will flash three times and then cancel, the digital flag indicator will turn off, and the output relay will return to the normal state.
2. Manual reset: press and hold the right/enter button on the front of the Omega 4 to reset the unit manually.
3. Remote reset: an external signal between 6 – 30V ac or dc can be applied to the reset terminals for a minimum of 10 secs.
4. Timed reset: in case the local LV supply is off for a sustained period, the EFI will reset in the time set for the Reset time in the menu system.

2.2.10 Commissioning

Omega 4 uses a new form of communication to that used previously by both Pathfinder 360 Alpha 4G and Sigma EFI 4G. This has been developed for the following reasons. Private APNs offer a level of security as only authorised SIMs can access the network, nominally this ensures that only certain devices can talk to each other and these can not be seen by the public internet.

However, security and authentication of communication is a solved problem and widely used on the public internet today. By not trusting any step in the communication and using end to end encryption with strong authentication, we do not need to worry about how the data is sent, as any interception would not give you access to the data. Each packet of data is signed with an authentication tag to prove who the packet came from and allows either end to reject a packet that has been tampered with.

Omega 4 can use the AES-256 symmetric algorithm, with a key controlled by Spring or our customers to encrypt the data on device and decrypt as close to the point of use as possible. Meaning there is no exposure of plain text data to the public internet.



Sources

<https://dev.blues.io/guides-and-tutorials/notecard-guides/encrypting-data-with-the-notecard/>

For further details on how to integrate Omega 4 with iHost, PowerOn or your specific control centre (Advanced Distribution Management System - ADMS) please contact Spring.

2.2.11 Installation

IMPORTANT - WARNING

1. The front section of the Omega 4 module should never be drilled as this contains the module electronics.
2. All Current Transformers should be connected to the Omega 4 module before being fitted in position round the cable.

Where practical Omega 4 box drilling's for fixing should be through corner fillets, which are outside the sealed enclosure area. If this cannot be achieved holes can be drilled through the main enclosure walls providing the weatherproof IP65 box seal can be maintained.

Alternatively, the Omega 4 module can be mounted on a zinc coated steel backplate. Please see 9.0 Mounting Data.

2.3 MODBUS Over RS485

The Omega 4 is fitted with an RS485 serial port. This is configured as standard as the following:

Baud rate: 9600

Bits per frame: 8

Parity: None

Stop bits: 1

Other configurations can be accommodated on request. The modbus address defaults to 1, but can be changed in the Modbus > Address menu. The Omega 4 uses the Modbus RTU protocol.

Address <8 bits>

function code <8 bits>

data <function dependent>

CRC <16 bits>

To simplify the protocol, only two function codes of Modbus will be implemented: read multiple holding registers and write holding register.

Code	Description	Data	Response
3	Read multiple holding registers	Address of first register <16 bits> Number of registers <16 bits>	Number of register bytes <8 bit> Register values <16 bits per register>
6	Write	Address of register <16 bits> Value to write <16 bits>	Number of register bytes <8 bit> Register values <16 bits per register>

It is convention to use register address ranges for different types of data. One convention is to use a digit at the beginning to signify the type of register. All data is considered Modbus type 4, so the addresses used in this specification have an implied 4 at the beginning of the address.

2.4 LoRa (Long Range) Radio Communication

The Omega 4 is fitted with LoRa radio hardware, operating at 860.70MHz for UK and


European operation and 915MHz for USA operation. This can be used for peer to peer communication, or peer to relay communication. Data can be sent over long distances without using the mobile network.

A relay can forward data to other peers or to the cloud to centralise an internet connection and reduce cost by removing the costs of a modem in each Omega 4.

3.0 Power Supply

- Option 1. Omega 4 BAT. The unit is powered by a Lithium Thionyl Chloride 3.6V 13Ah integral Battery with up to 10 years life depending on operational usage and environmental temperatures.
- Option 2. Omega 4 LV. The unit includes a power supply board in the backbox. This allows the Sigma to be powered from LV mains at 230Vac. Note: the unit still requires a 3.6V 13Ah battery to be fitted.
- Option 3. Omega 4 RTU. The unit is powered by a 12V or 24V d.c. supply from an RTU


Battery Calculations based on:
150 Flashing hours per year
100 GSM/GPRS calls per year



4.0 Connections


The example below shows an LV powered backbox.
Fig 4.1

Note: Remove Black Plastic cover to make 230Vac LV mains connection




The example below shows a Battery powered backbox.

Fig 4.2



The example below shows the Omega 4 screw terminal connections

Fig 4.3



Note: internal antenna as standard, external antennae optional

5.0 Testing of Installation and Primary Injection Testing

The following primary current tests prove the alarm functions and the Current Transformer input circuits.


Manual Testing

Available on all models with the Push Button Control. The twin LEDs will flash and a status 4G message will be initiated.

Primary Injection Testing

This test is applicable to all Omega 4 models and can only be carried out if the Omega 4 modules are connected to a Core Balance Current Transformer for earth fault testing or 3 x Phase C/Ts for overcurrent testing. The test will confirm the correct operation of all modules and Band Current Transformer functions.

Sufficient primary current must be passed through the Current Transformer to cause the module to alarm. The Omega 4 is set to operate at a fault current (e.g. 60A) above the user set current (e.g. 50A) threshold. Once triggered the module can either be left to reset automatically after its selected reset time, reset manually or using the LV reset option. The primary current can be generated with a suitable a.c. current injection test set or with the Bowdens Portable EFI Tester.



LV Reset

Connect the 230/240V 50 Hz local reset supply to the terminals in the base of the Omega 4 unit. If the Omega 4 has tripped and the Volts lost from the local supply, as soon as the local supply returns for a period of 15 seconds the Omega 4 Alarm will be reset.

6.0 Current transformer installation

Omega 4 can operate with a Core Balance C/T for Earth Fault only indication or from 3 x Phase C/Ts for Overcurrent and Earth Fault Indication. Most C/T ratios can be accommodated via the C/T matching function in the program settings. The Omega 4 is also designed to operate from the 1000:1 Bowdens Band C/T. Install the C/T according to Drawing 1 taking note of how the earthing should be applied to the C/T. Test the installation using Bowdens Portable EFI Tester - (see 5.0 Testing of installation).

Drawing 1




FIG 6.1

Traditional external cast resin C/T installation. Insulated gland at entry to cable box. An earth braid needs to be soldered to the earth termination and brought back through the C/T to cancel the earth fault flowing in the cable sheath.

FIG 6.2

Sheath earth terminates at insulated gland and so the C/T can be installed in the base of the cable box where it will detect only out of balance caused by earth fault flowing in one phase.





FIG 6.3

Individual phases enter cable termination box separately. A large diameter band type C/T can be placed in the base of the cable box to encompass all three phases. If the earth terminates above the C/T position then it must be collectively brought back through the C/T as shown.

FIG 6.4

Alternatively individual phase C/Ts may be installed, and summated in parallel for earth fault output, or as phase C/Ts for Overcurrent and Earth Fault EFI. If the Earth terminates above the C/T position then it must be collectively brought back through the C/T as shown.






Fig 6.5

Individual phase C/T's may be installed and summated in parallel for earth fault output, or as a phase C/T's for overcurrent and Earth Fault EFI. If the earth terminates below the C/T position then it will read pure fault current.

Correct Core Balance CT Orientation

External CT and RMU with insulated cable gland

Drawing 2a




Key:

- Omega 4 module and cable to CT
- Core balance current transformer

Correct Core Balance CT Orientation

Internal CT's inside RMU dry cable box

Drawing 2b



Key:

- Omega 4 module and cable to CT
- Core balance current transformer
- ⌋ Earth wire through CT



This type of installation requires an insulated cable gland (or alternative) at each cable location where the Omega 4 core balance CT is fitted. In addition the earth wire between cable gland and switchgear must be directed through the CT.


Where there are Omega 4 installations along a common HV cable circuit it is essential that the CT's are correctly orientated relative to each other.

Each CT has a P1 and P2 primary side, and S1 and S2 secondary terminals. Incorrect orientation of these features will cause incorrect Directional Indication of the Omega 4. The Overcurrent and Earth Fault indications will not be affected.

Each CT will require identification on its P1 side. The CT's secondary terminal S1 will also need to be identified. For a Bowdens Band CT S1 is the Blue lead. The other terminal will logically be S2.


In order to give correct current direction to the omega 4 all the CT's on cables electrically connected nearest to source 'A' must have the same orientation ie. P1 on top. The S1 and S2 connections must be the same at each corresponding omega 4 location.

Band Current Transformer Outline **Phase C/Ts 50mm ID & Core Balance 120mm ID** Drawing 3a




IMPORTANT

Method of determining P1 side of CT.
 Hold CT in Left Hand and secondary cable in Right Hand.
 The 'P1' Side of the CT is the side facing you.
 The 'S1' Secondary Output is BLUE



Not to Scale
 Dimension in mm


Split Core Cast Resin Current Transformer Outline (available in ratios 500:1, 60:1, 40:1) Drawing 3b



SPLIT EFI Cast Resin Current Transformer with Terminal Box
OUTLINE DRAWING DKM 1246/B

OMEGA 4 Programmable Fault Passage Indicator Outline (Dimensions in mm & not to scale)

Drawing 4



7.0 Type Testing

Temperature Tests

IEC 60068 - Equipment fitted outdoors shall operate over the temperature range -20° C to + 80° C. The components and assemblies used in OMEGA 4 modules meet this temperature requirement.

Shock Withstand Tests

IEC 60255-21-2 Shock Withstand:

A random selection of modules were tested. Slight abrasions were observed, however the polycarbonate did not chip or crack. A primary current test was carried out on each module after each test. The module was found to be unaffected by the mechanical vibration. After five tests each module was fitted to a Band Current Transformer and the complete assembly tested with a primary current. All tests were successful.

Environmental & Climatic Tests

IEC60068 - Modules have been left submerged continuously under a 300mm head of water. Modules are continually left in an outdoor exposed situation where the effects of weather and natural temperature cycling can be observed.

Electro-magnetic Compatibility Tests

Generic EMC Standards

BS EN 61000-6-4: 2001

BS EN55011:1998 + A1:1999

BS EN55011:1998 + A1:1999

- Generic emissions standard (Heavy industrial)
- Radiated Emissions.
- Conducted Emissions.

BS EN 61000-6-2: 2001

- Generic immunity standard (Heavy industrial)

BS EN 61000-4-2:1995 + A1 1998 + A2:2001

- Electrostatic discharge Immunity Test

BS EN 61000-4-3:2002 + A1:2002

- Radiated Immunity.

BS EN 61000-4-4:1995 + A1:2001+A2:2001

- Fast Transient/Bursts Immunity.

BS EN 61000-4-5:1995 +A2:2001

- Surge Immunity.

BS EN 61000-4-6: 1996 + A2:2001

- Conducted RF Immunity

BS EN 61000-4-8: 1996 + A2:2001

- Magnetic Immunity

Additional EMC Testing to meet power system environmental requirements

TEST 1	-BS EN 61000-4-8: 1994 50Hz Magnetic Field up to 6mT (5000A/m) continued stable for 3 seconds.
TEST 2	-BS EN 61000-4-11:1994 + A1:2001 - Voltage Dips and Interruptions
TEST 3	-BS EN 60255-5: 2001

8.0 Specification OMEGA 4

General Data

Module case	:	Polycarbonate material. Case to IP66 (dust and water jet proof)
Temperature range	:	-25°C to + 70° C

Threshold Levels – User Settable

EF Trip Current	:	20 – 120A
Phase Trip Current	:	125 – 750A
EF Trip delay	:	Pre-set at 50ms nominal
Phase Trip Delay	:	Pre-set at 100ms
Reset time	:	Pre-set at 6 hours +/- 10 mins
Accuracy	:	+/- 5A from any Bowdens C/T

Reset Options

Manual	:	Push Button
LV Reset Signal	:	Only available with power supply board
Timed Reset	:	1 to 12 hours
Remote Reset	:	Via RTU Volts free relay signal

Alarm Mode


Permanent Faults	:	LEDs flash alternatively every 1.5 seconds
Digital Flag Indicator	:	Shows warning triangle and fault direction
Transient Faults	:	LED gives two short flashes every three seconds for 24 hrs. Occurs 15 secs after LV Reset.

Enable/Disable Transient switch

After Ready Mode/Reset	:	Three flashes
Second Fault Alarm	:	Alert to second faults during Alarmed Mode
Power Source	:	Lithium battery 3.6V 13Ah. Battery Life 10 years.
Alarm Output Relay	:	Two sets of Volt free contacts (NO, COM, NC)

9.0 Mounting Data

OMEGA Fixing Holes in Base



HOLES 'A'	Corner fillet holes for fixing OMEGA 4 base Holes 4mm diameter Distances between centres Dimensions in mm Not to scale
HOLES 'B'	Recessed screw holes for securing OMEGA 4 front panel

10. Modbus Registers

For all items see 2.1.2 and 2.1.3 for further explanation

Live	Register Number	Type
Battery	9	int16 read only
Temp	3	int16 read only
Phase 1	4	int16 read only
Phase 2	5	int16 read only
Phase 3	6	int16 read only
Earth	7	int16 read only
LV freq	8	int16 read only
Faults	150	int16 read only ¹
Last Fault Type	151	int16 read only
Last Fault DateTime	156	uint32 (unix time) read only
Last Fault Phase 1	153	int16 read only
Last Fault Phase 2	154	int16 read only
Last Fault Phase 3	155	int16 read only
Last Fault Earth	152	int16 read only
Last Fault P1 angle	158	int16 read only
Last Fault P2 angle	159	int16 read only
Last Fault P3 angle	160	int16 read only
Last Fault Earth angle	157	int16 read only
Test alarm	116	int16 read / write
Mode	111	int16 read / write
CT ratio	102	int16 read / write
Bias fitted	113	int16 read / write
EF trip	103	int16 read / write
EF delay	104	int16 read / write
OC trip	105	int16 read / write
OC delay	106	int16 read / write
Relay mode	112	int16 read / write
Reset time	107	int16 read / write
Reset LV	109	int16 read / write
Reset LV time	110	int16 read / write

¹ - Faults register shows which phases were over threshold, if bit 0 is set, then the earth current was above threshold. If bit 1 is set, phase 1 was above threshold. If bit 2 is set, then phase 2 was over threshold. If bit 3 is set, then phase 3 was over threshold.

VERSION 2.0
RELEASE 11.06.25

ECO Reference	Date
ECO0290	11.06.25