

Note: Servicing should only be attempted by suitably skilled personnel.
For more info about this or training courses, contact Drive Medical

Does not require servicing
 Servicing required

	Steel Wheelchair	Travel Chair	Alu. Wheelchair	Folding Powerchair	Fixed Base Powerchair	Boot Scooter	Class 2 Scooters	Class 3 Scooters		Steel Wheelchair	Travel Chair	Alu. Wheelchair	Folding Powerchair	Fixed Base Powerchair	Boot Scooter	Class 2 Scooters	Class 3 Scooters
Section 1: Controller																	
On/Off Switch	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Joystick / Wigwag	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Joystick Gaitor	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Output Plug	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Seal	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Operation	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Dynamic Braking	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Static Braking	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 2: Batteries																	
Type (SLA/AGM/Gel)	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Compartment	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Connections	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Wirings	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Battery Test	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 3: Wheels																	
Tyre Pressure	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Tyre Wear	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Wheel Bearings	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Hub Caps / Disks	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Wheel Nuts Tight	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Tab Washers	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Lubricated / Greased	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 4: Chassis / Frame																	
General Condition	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Castor Assemblies	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Manual Brakes	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Suspension	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Steering Linkage	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Swivel Bearings	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Tiller Pivot	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Handbrake	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Footrest Lock Mechanism	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 5: Motor/s																	
Wiring	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Mounting	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Function	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Noise Level	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Commutator Cleaned	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Brushes	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 6: Upholstery																	
Seat	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Back	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Armpads	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Pouch	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Hood Tiller	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 7: Body																	
Mounting	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Condition	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Seat Mechanism	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Seat Adjustment	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 8: Electrics																	
Condition of Loom	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Lights	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Audible Warnings	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Charger	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Charger Connection	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 9: Drive Train																	
Transaxle Seals	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Transaxle Noise Lever	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Transaxle Mount Brackets	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Section 10: Test Run																	
Test Run	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■