

## Draper Expert Lambda/Oxygen Sensor Socket Set, 3/8", 1/2" Sq. Dr. (7 Piece)

**STOCK No.** 89765 **BRAND** Draper Expert

**BARCODE** 5010559897650

**WARRANTY** 12 months parts and labour

### FEATURES

- For removal, inspection or replacement of heated and non-heated oxygen sensors fitted to Audi, BMW, Citroën, Mercedes, Peugeot, Renault, Skoda, GM (Vauxhall/Opel) and Volkswagen
- Cut-away sections allow some sockets to fit over wiring harnesses
- Sockets have black phosphate finish for corrosion protection
- Includes grooved, window and offset sockets
- Supplied in a sturdy plastic storage case



### DESCRIPTION

For removal, inspection or replacement of heated and non-heated oxygen sensors fitted to the following vehicle marques; Audi, BMW, Citroën, Mercedes, Peugeot, Renault, Skoda, GM (Vauxhall/Opel) and Volkswagen. Cut-away sections allow some socket to fit over wiring harnesses. socket have black phosphate finish. in blow moulded case.

**1 x 3/8" Sq. Dr. 80mm deep socket with 7.7mm wide long groove**

**1 x 3/8" Sq. Dr. deep socket with 20.5mm wide long groove**

**1 x 3/8" Sq. Dr. Offset square drive socket with 8.6mm wide full length groove**

**1 x 3/8" Sq. Dr. 1.1/16" x 74mm deep socket**

**1 x 1/2" Sq. Dr. Offset square drive deep socket 22 x 49.5mm with 11mm wide full length groove**

**27 x 1/2" Sq. Dr. 85mm deep socket with large side viewing window**

**29 x 1/2" Sq. Dr. 90mm deep socket with 8.2mm wide long groove**

**1 x 3/8" Sq. Dr. 80mm deep socket with 7.7mm wide long groove**

**1 x 3/8" Sq. Dr. deep socket with 20.5mm wide long groove**

**1 x 3/8" Sq. Dr. Offset square drive socket with 8.6mm wide full length groove**

**1 x 3/8" Sq. Dr. 1.1/16" x 74mm deep socket**

**1 x 1/2" Sq. Dr. Offset square drive deep socket 22 x 49.5mm with 11mm wide full length groove**

**27 x 1/2" Sq. Dr. 85mm deep socket with large side viewing window**

**29 x 1/2" Sq. Dr. 90mm deep socket with 8.2mm wide long groove**

[Link to product - drapertools.com](https://www.drapertools.com)

---

## CONTENTS

- 1 x Deep socket with 7.7mm wide long groove, 3/8" Sq. Dr., 80mm
- 1 x Deep socket with 20.5mm wide long groove, 3/8" Sq. Dr.
- 1 x Offset square drive socket with 8.6mm wide full length groove, 3/8" Sq. Dr.
- 1 x Deep socket, 3/8" Sq. Dr., 1.1/16" x 74mm
- 1 x Offset square drive deep socket 22 x 49.5mm with 11mm wide full length groove, 1/2" Sq. Dr.
- 27 x Deep socket with large side viewing window, 1/2" Sq. Dr., 85mm
- 29 x Deep socket with 8.2mm wide long groove, 1/2" Sq. Dr. 90mm