

Fitting Instructions

Thank you for purchasing the Armaplate LockNut security device. This unit will help to protect your shed/garage from opportunist theft-attacks. The unit comes with a 5-year guarantee against manufacturing defects, so please be sure to **keep your receipt safe**.

You will require a drill with a 6.5mm steel drill-bit, a 10mm spanner and a hacksaw. Please take your time when determining where to drill holes and double-check all your measurements before proceeding.

The LockNut has slotted fixing points to ease fitting and can be fitted in a variety of positions. Find a position on your doors where the long fixing bolts will be able to reach all the way through from the outside to the inside without fouling anything. Both doors (or door and frame) must be flush.

Once you've found the best place on your doors for the LockNut, hold one half of the fixing bracket onto the edge of the door and mark the drill-locations with a marker pen. Check again that the bolts will be able to go through the door at that point and that you'll be able to fit a nut and washer on the other end. Drill two holes and then treat the holes with touch-up paint and allow to dry (if fitting to a painted garage doors).

Bolt the bracket loosely in place, before repeating the process on the other door, carefully matching up the two fixing brackets so that they are **perfectly in line** with one another. If fitting to a painted surface, fit the supplied gaskets to the back of the brackets. When you're happy that the second fixing-bracket is in the right location in relation to the first one, mark the drill-holes, then drill them.

Bolt the bracket loosely in place. Check the alignment of the two brackets again, making sure that they match up perfectly before tightening the nuts. Now attach the padlock section and check that it fits neatly into place with an even gap all around. If not, loosen the fixing bolts and adjust the brackets slightly to correct.

