

## Fitting

1. Fit Datum Block into channel
2. Rotate Datum Block 90° (Anti-Clockwise) using Boa Key, to lock into channel
3. Slide Spacer Bar Assembly to Locate under Datum Block
4. Position Slider Bar Assembly to fit inside stop in Stay channel

Tapped Block position



Commercial version is fitted the same with additional operation of fitting a tapped block to Spacer Bar Assembly, rotated 90° (Anti-Clockwise), retained in position with Security Lock Screw. Tapped Block is positioned on Bar just below Rivet Block as shown in pics 3, 4 & 5