



**STEP 1**

Select correct hand to suit application (L. Hand shown).

**STEP 2**

Fit to the frame using suitable screws and into re-enforcement where possible.  
*Note.* To give best access for un-latching, fit the towards the back of the frame.

**STEP 3**

Position the stud plate on the sash  
*Note* The stud plate must be positioned so that it is inline with the when the window is closed (see fig 3) and the stud is inline with the alignment mark on the Fit using suitable screws and into re-enforcement were possible.

**NOTE.**

On certain window profiles with deep locating ribs in the frame section, it may be necessary to locally remove a small section of these ribs to allow free movement of the stud into the frame.