



To assembly to wall 9mm holes must be drilled approx. 100 mm from the sides at the back of the hood.

Wall must be drilled for the anchors and assembled with the given anchoring screws.

Number of anchoring screws are given below.

NOTE: Power cable is not included for hoods with lighting.

HOOD LENGTH
L (mm)

ANCHORING PCS.

Between 1000-2000

4 Pcs.

Between 2000-3000

6 Pcs.

3500

8 Pcs.

Beyond 4000

12 Pcs.

ÇÖZÜM