

## TT ASSEMBLY AREA (PARC FERME) IMPORTANT SAFETY INFORMATION

Tyre warmers are only to be plugged into the sockets in Parc Ferme using the 16 Amp connection shown below



All leads are to be labelled to show the kit has been tested  
Blue extension leads are to be Artic blue 1.5mm 3core flex as a minimum.  
All extension cables are to fully unwind to prevent overheating  
An example of bad practice is shown below:

