


Anziehvorschrift für Zylinderkopf		549.350 passend für / suitable for adaptable à / adaptable a Mercedes Benz	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
132.180 M10x1,5x165				
Anziehen/ Tightening/ Serrage/ Apriete	M10 * 45 Nm ➤ 90° ➤ 90°	M8 20 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
1.8 Ltr. Turbo				
Mot: M 271.820,860				
115-150 KW (156-204 PS)				
W204 C180CGI, C200CGI, C250CGI				
W212 E200CGI, E250CGI				
C207/A207 E200CGI, E250CGI				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*549.350*	