



MC6

-

FIONDA

Jasper

Morrison



MATTIAZZI

ITALY



MATERIAL

Ash or oak of European origin and legal wood cutting (controlled deforestation). Teak of Asian origin.

MAINTENANCE

It is suggested to clean the product with a soft and damp cloth or with specific detergents for furniture. Do not use abrasive sponges or other materials potentially aggressive. Do not use acid products, solvents or products containing ammonia. Fabric can be handwashed with Marseille soap. Do not tumble dry. In order to preserve the color of the teak wood for outdoor use and to avoid that the surface turns gray, we advise you to use occasionally some oil for outdoor furniture. This maintenance is necessary to avoid the micro-cracks of the wood caused by environmental influences, which do not compromise the stability of the product. It is suggested to use Fionda in areas protected from sun and rain during outdoor use. Teak frames have to be treated regularly with oil for outdoor furniture. Suggested oil: Auro Natural Paints – Terrace oil, Teak n. 110 - 81.

WARNINGS

Avoid to stand on the seat/top of the product.
Avoid to use the product as ladder.
Avoid to rock the product when sitting.
Avoid to stand on the raised parts.
Avoid any other improper use not in compliance with the proper one.

RECOVERY START

At the end of its use, the product can be destined to the recovery according to the ordinary channels.

LEGAL PROVISIONS

This product sheet is in compliance with the Legislative Decree d. lgs. 206 / 2005 (Consumer Code) and with the corresponding Ministerial Decree for the implementation of art. 6 and 10.

MATTIAZZI REFUSES ANY RESPONSIBILITY FOR DAMAGES
CAUSED TO PERSONS OR THINGS DERIVING FROM AN
IMPROPER USE OF THE PRODUCT.