

- Fire alarm panel Zone 1, zones
- Ground floor Zone 1
 - Ground floor Zone 2
 - Ground floor Zone 3
 - First floor Zone 4
 - First floor Zone 5
 - First floor Zone 6
 - Ground floor Zone 7
 - Ground floor Zone 9
 - Ground/First floor Zone 11

- Fire alarm panel Zone 2, zones
- Ground floor Zone 1
 - Ground floor Zone 2
 - Ground floor Zone 3
 - First floor Zone 4
 - First floor Zone 5
 - First floor Zone 6
 - Zone 7 (Link to Old Block)
 - Zone 8 (Dry Goods Sprinkler)
 - Zone 9 (Thermal Oil Sprinkler)

SITE DIAGRAM
 Showing fire panel location and zones covered by each panel

FAB Fire alarm board, - 1 = Zone 1 - 2 = Zone 2

D Heat/Smoke Detector

