

# ***Hanging Instructions***

## CAUTION


This product is heavy. Please use at least two strong fixing points to hang this picture frame. Wall fixings are not included as hanging surfaces vary.

Wall plugs and screws must be compatible with the construction and material of the wall and suitable for holding the weight of the frames. If in doubt, seek professional advice.


**DO NOT** use picture wire as this will create a strain on the hangers and could result in failure of the fittings.

This picture frame has been designed to be hung as shown below. Failure to follow these directions may result in a safety hazard.


1. Choose wall anchors suitable for the type of wall (stone, brick, cavity etc.) and the size and weight of the frame to be hung.



2. Measure the distance between the hanging brackets (A & B).



3. Measure the same distance on the wall, ensuring that the two points are level and mark the wall where the frame is to be hung (A & B).



4. Drill holes at B and C to accept the wall anchors.
5. Insert the wall anchors.
6. Insert suitable screws/bolts, leaving approximately 1cm of the screw and screw head protruding to safely accept the hanging brackets.



7. The hanging brackets should be hung directly on these screws.