

Combination Change Instructions

Step 1:

Set the combination to the number that opens the lock. Factory default 0-0-0

Step 2:

Push the change button (located on the bottom of the lock) with a paperclip while setting a new combination

Step 3:

Release pressure on the change button by removing the paperclip

Change your combination any time and as often as you like