



# PETROL CULTIVATOR/ TILLER

## 10036 - CP145/B SPARE PARTS LISTING

Key No.	Part No.	Stock No.	Description	Key No.	Part No.	Stock No.	Description
1	YCP145-01	34882	Bolt M5x35	41	YCP145-41	40311	Bolt M6x44
2	YCP145-02	35239	Bolt Ø8.4x20x2	42	YCP145-42	40312	Right handrail
3	YCP145-03	35523	Right rotary knife	44	YCP145-44	40313	Throttle cable
4	YCP145-04	35534	Gear box	45	YCP145-45	40403	Clip
5	YCP145-05	36190	Washer Ø8	46	YCP145-46	40409	Bolt M8x16
6	YCP145-06	36192	Plugging cover	47	YCP145-47	40410	Handrails clip
7	YCP145-07	36210	Circlip Ø2	48	YCP145-48	40412	Washer GB96 Ø8.4x24x2
8	YCP145-08	36215	Light rotary blade	49	YCP145-49	40415	Washer GB93 8.1x2.1
9	YCP145-09	36216	Fender	50	YCP145-50	40422	Handrails stent
10	YCP145-10	36329	Clevis pin with head 8x35	51	YCP145-51	40428	Circlip
11	YCP145-11	36331	Front wheel	52	YCP145-52	40457	Driven pulley
12	YCP145-12	36646	Nylon washer	53	YCP145-53	40459	Washer Ø13.2xØ24x1.5
13	YCP145-13	37323	Bolt	54	YCP145-54	40771	Gearbox stent
14	YCP145-14	37473	Wheel fixator	55	YCP145-55	40772	Resistance pole
15	YCP145-15	37548	Bolt GB5782 M10x65	56	YCP145-56	40773	Tension pulley
16	YCP145-16	38013	Nut GB6182 M10	57	YCP145-57	40774	Spring
17	YCP145-17	38217	Spring	58	YCP145-58	40775	Bolt M6x16
18	YCP145-18	38400	Bolt M8x20	59			
19	YCP145-19	38800	Belt VZ610	60			
20	YCP145-20	39043	Bolt BS17689 3/8UNFX30	61			
21	YCP145-21	39177	Washer GB96 Ø10.5x30x2.5	62			
22	YCP145-22	39600	Initiative pulley	63			
23	YCP145-23	39602	Nut M5	64			
24	YCP145-24	39603	Flat key 4.75x5.5x25	65			
25	YCP145-25	40001	Belt	66			
26	YCP145-26	40079	Bolt M8x30	67			
27	YCP145-27	40094	Engine fixator	68			
28	YCP145-28	40096	Nut M8	69			
29	YCP145-29	40101	Clutch spring	70			
30	YCP145-30	40127	Bolt M8x40	71			
31	YCP145-31	40173	Clutch handle	72			
32	YCP145-32	40183	Clutching line	73			
33	YCP145-33	40189	Left handrail	74			
34	YCP145-34	40195	Handle cover	75			
35	YCP145-35	40196	Nut M8	76			
36	YCP145-36	40198	Nut M6	77			
37	YCP145-37	40199	Clutch spring	78			
38	YCP145-38	40272	Throttle switch cover (L)	79			
39	YCP145-39	40309	Throttle switch handle	80			
40	YCP145-40	40310	Throttle switch cover (R)	81			



# PETROL CULTIVATOR/ TILLER

## 10036 - CP145/B SPARE PARTS LISTING

Key No.	Part No.	Stock No.	Description	Key No.	Part No.	Stock No.	Description
11	YCP145-73	41547	Spark plug	51	YCP145-113	43408	Nut
12	YCP145-74	41559	Cover, recoil	52	YCP145-114	43409	Shroud assy, upper
13	YCP145-75	41693	Bolt M6x25	53	YCP145-115	43410	Tube, breather
14	YCP145-76	42041	Wind deflector shall be left	54	YCP145-116	43411	Clip, wire harness
15	YCP145-77	42089	Plate, governor	55	YCP145-117	43412	Crankshaft assy
16	YCP145-78	42090	Rod, push	56	YCP145-118	43413	Nut
17	YCP145-79	42092	Lifter, valve	57	YCP145-119	43420	Washer, crankshaft
18	YCP145-80	42100	Camshaft assy	58	YCP145-120	43434	Governor assembly
19	YCP145-81	42141	Scraper ring set, piston	59	YCP145-121	43450	Gasket, breather chamber
20	YCP145-82	42282	Piston	60	YCP145-122	43455	Cap, breather chamber
21	YCP145-83	42542	Pin, piston	61	YCP145-123	43756	Dowel pin, casecover
22	YCP145-84	42543	Clip, piston	62	YCP145-124	43856	Cover assembly, crankcase
23	YCP145-85	42558	Rod assembly., Connecting	63	YCP145-125	43870	Oil seal
24	YCP145-86	42562	Cylinder	64	YCP145-126	43994	Bolt M6x18
25	YCP145-87	42563	Oil seal	65	YCP145-127	44046	Bolt M6x45
26	YCP145-88	42586	Nut, flange	66	YCP145-128	44061	Tube
27	YCP145-89	42609	Adjuster rocker arm	67	YCP145-129	44065	Clip, fuel line
28	YCP145-90	42611	Shroud	68	YCP145-130	44068	Dipstick
29	YCP145-91	42612	Engine stop wire	69	YCP145-131	44069	Nut M6
30	YCP145-92	42614	Circular plate	70	YCP145-132	44073	Clamp, breather tube
31	YCP145-93	42627	Breathing valve spring	71	YCP145-133	44074	Ignition coil assy
32	YCP145-94	42629	Bolt, stud	72	YCP145-134	44075	Bolt stud, ignition coil
33	YCP145-95	42634	Fuel tank cap comp	73	YCP145-135	44080	Bolt stud, recoil starter
34	YCP145-96	42886	Fuel tank	74	YCP145-136	44092	Flywheel assembly
35	YCP145-97	43003	Bolt M6x38	75	YCP145-137	44082	Fan, recoil starter
36	YCP145-98	43005	Bushing, fuel tank	76	YCP145-138	44095	Pulley, starter
37	YCP145-99	43019	Bolt M6x16	77	YCP145-139	44103	Nut
38	YCP145-100	43024	Engine stop wire	78	YCP145-140	44137	Shield, muffler
39	YCP145-101	43027	Clip, fuel line	79	YCP145-141	44152	Gasket, air cleaner
40	YCP145-102	43029	Fuel line	80	YCP145-142	44239	Air cleaner assembly
41	YCP145-103	43033	Shaft, governor arm	81	YCP145-143	44241	Bolt, stud
42	YCP145-104	43034	Washer, governor arm shaft	82	YCP145-144	44369	Packing, intake
43	YCP145-105	43035	Seal, governor arm shaft	83	YCP145-145	44377	Insulator, carburetor
44	YCP145-106	43036	Pin, lock	84	YCP145-146	44393	Packing, carburetor
45	YCP145-107	43037	Governor arm	85	YCP145-147	44400	Carburetor assy
46	YCP145-108	43105	Bolt, governor arm	86	YCP145-148	44426	Gasket, exhaust
47	YCP145-109	43308	Hexagon bolts with flange	87	YCP145-149	44484	Muffler assy
48	YCP145-110	43312	Rod, governor	88	YCP145-150	44489	Filter, breather
49	YCP145-111	43370	Spring, throttle return	89	YCP145-151	44490	Filter
50	YCP145-112	43407	Spring, governor	90	YCP145-152	44491	Damper putter