


AIR DRILL

84121 - DAT-RAD13 SPARE PARTS LISTING



KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YDAT-RAD13-1	00490	Main Housing
2	YDAT-RAD13-2	00491	Bolt
3	YDAT-RAD13-3	00493	Muffler Cover
4	YDAT-RAD13-4	00494	Gasket
5	YDAT-RAD13-5	00495	Air Inlet
6	YDAT-RAD13-6	00496	O-Ring
7	YDAT-RAD13-7	00497	O-Ring
8	YDAT-RAD13-8	00498	Valve Stem
9	YDAT-RAD13-9	00499	O-Ring
10	YDAT-RAD13-10	00500	Screw
11	YDAT-RAD13-11	00501	O-Ring
12	YDAT-RAD13-12	00502	F/R Lever
13	YDAT-RAD13-13	00503	Cover Plate
14	YDAT-RAD13-14	00504	Spring
15	YDAT-RAD13-15	00505	Set Screw
16	YDAT-RAD13-16	00506	Trigger
17	YDAT-RAD13-17	00507	Cylinder Gasket
18	YDAT-RAD13-18	00508	Bearing
19	YDAT-RAD13-19	00510	Rear Plate
20	YDAT-RAD13-20	00511	Rotor
21	YDAT-RAD13-21	00512	Rotor Blades
22	YDAT-RAD13-22	00513	Cylinder

KEY No.	PART No.	STOCK No.	DESCRIPTION
23	YDAT-RAD13-23	00514	Bolt
24	YDAT-RAD13-24	00515	Front Plate
25	YDAT-RAD13-25	00516	Bush
26	YDAT-RAD13-26	00518	Middle Gear
27	YDAT-RAD13-27	00519	Minor Gear
28	YDAT-RAD13-28	00520	Pin
29	YDAT-RAD13-29	00521	Gear Stand
30	YDAT-RAD13-30	00522	Major Gear
31	YDAT-RAD13-31	00524	Spindle
32	YDAT-RAD13-32	00526	Gear Ring
33	YDAT-RAD13-33	00527	Bearing
34	YDAT-RAD13-34	00528	Clamp Nut
35	YDAT-RAD13-35	00529	Washer
36	YDAT-RAD13-36	00530	Kelyless Chuck
37	YDAT-RAD13-37	00531	Set Screw
38	YDAT-RAD13-38	00532	Copper Ring
39	YDAT-RAD13-39	00534	Auxiliary Handle
40	YDAT-RAD13-40	02069	Soft Grip
41	YDAT-RAD13-41	02070	Trigger Nut
42	YDAT-RAD13-42	02071	Trigger Spring
43	YDAT-RAD13-43	02072	Soft Grip Set