

DRAPER

EN

Original Instructions
Version 2
July 2025

WET & DRY

VACUUM CLEANER

06489



**UK
CA** **CE**

1. Preface

1.1 Product Reference

User Manual for: Wet & Dry Vacuum Cleaner

Stock No: 06489

Part No: WDV10

1.2 Revisions

Version 1: September 2021

First release

Version 2: July 2025

As our manuals are continually updated, always ensure that the latest version is used.

Please visit [drapertools.com/manuals](https://www.drapertools.com/manuals) for the latest version of this manual and the associated parts list, if applicable.

1.3 Understanding the Safety Content of This Manual

 **WARNING!** – Situations or actions that may result in personal injury or death.

 **CAUTION!** – Situations or actions that may result in damage to the product or surroundings.

Important: – Information or instructions of particular importance.

1.4 Copyright © Notice

Copyright © Draper Tools Limited.

Permission is granted to reproduce this manual for personal and educational use **ONLY**. Commercial copying, redistribution, hiring or lending is strictly prohibited.

No part of this manual may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases, this copyright notice must remain intact.

2. Contents

1. Preface	2
1.1 Product Reference	2
1.2 Revisions	2
1.3 Understanding the Safety Content of This Manual	2
1.4 Copyright © Notice	2
2. Contents	2
3. Product Introduction	3
3.1 Intended Use	3
3.2 Specification	3
4. Health and Safety Information	3-4
4.1 General Health and Safety Precautions	3
4.2 Additional Health & Safety Precautions for Vacuum Cleaners	4
4.3 Connection to the Power Supply	4
4.4 Residual Risk	4
5. Identification and Unpacking	5
5.1 Product Overview	5
5.2 Packaging	5
6. Preparation Instructions	6
6.1 Setting up the Vacuum Cleaner	6
7. Operation Instructions	7
7.1 Dry Vacuuming	7
7.2 Wet Vacuuming	7
7.3 Blower Function	7
8. Maintenance and Troubleshooting	7-8
8.1 Troubleshooting	8
9. Spares, Returns and Disposal	8
10. Warranty	8

3. Product Introduction

3.1 Intended Use

This vacuum cleaner is designed to pick up both wet and dry material. Ideally suited for use around the home and car cleaning.


Any other application beyond the conditions established for use will be considered misuse. Draper Tools accepts no responsibility for improper use of this product.

Read this manual in full before attempting to assemble, operate or maintain the product, and retain it for later use.

3.2 Specification

Stock No.	06489
Part No.	WDV10
Rated voltage:	230V/50Hz
Rated input:	1000W
Accessories diameter:	35mm
Maximum vacuum pressure:	11kPa
Maximum air flow:	30L/sec
Tank capacity:	10L
Liquid volume:	5L
Noise emissions	
Sound pressure level:	82dB (A)
Sound power level:	96dB (A)
Power consumption (OFF mode):	0.0W
Cord length (approx.):	3.5M
Net weight (including accessories):	3.8kg

Important: The noise emissions values have been measured in accordance with a standard test method and may be used for comparing one tool with another. These values may also be used in a preliminary assessment of exposure.

 **WARNING!** The noise emissions during actual use of the product can differ from the declared values depending on the type of work and the area upon which it is used. Before each use, estimate the likely exposure resulting from the actual conditions of use. Take into account all parts of the operation cycle in order to identify any safety measures required to protect the operator.

4. Health and Safety Information

Important: Read all the Health and Safety instructions before attempting to operate, maintain or repair this product. Failure to follow these instructions may result in injury or damage to the user or the product.

4.1 General Health and Safety Precautions

 **WARNING!**

- To reduce the risk of electric shock or injury:.
- **DO NOT** leave the appliance unattended when plugged in or switched on.
 - **ALWAYS** switch off and unplug from the power supply when not in use, changing accessories or performing any cleaning or maintenance.
 - **DO NOT** use this appliance near flammable liquids, gases or explosive vapours or dust. Sparks inside the motor can ignite flammable vapours or dust.
 - **DANGER! DO NOT** vacuum hot or glowing ash, cigarette ends, matches or anything that is burning.
 - Keep the cord away from hot surfaces and sharp edges.
 - For indoors use only. **DO NOT** expose to rain or very damp conditions.
 - **DO NOT** pull or carry the appliance by the power cord.
 - **DO NOT** pull the plug from the socket by the cord. To unplug grasp by the plug, not the cord.
 - **DO NOT** use with a damaged or worn cord, plug or any other part s.
 - If the appliance is not working, has been damaged, left outside or dropped in water, get it checked and repaired by a qualified person.
 - **DO NOT** run the appliance over the cord.
 - **DO NOT** touch the cord or appliance with wet hands.
 - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

4.2 Additional Health & Safety Precautions for Vacuum Cleaners

- **DO NOT** modify the appliance and only use for its intended use.
- Wear protective clothing and gloves.
- **DO NOT** allow untrained persons to operate the cleaner.
- To reduce the risk of health hazards from vapours and dust, **DO NOT** vacuum toxic materials.
- **DO NOT** use or store near hazardous materials.
- **DO NOT** use with a damaged filter or without a filter installed.
- **DO NOT** place any objects into the ventilation openings and **DO NOT** use if the ventilation openings are blocked.
- The hose should be checked regularly and must not be used if damaged.
- Unplug before connecting the hose.
- To reduce the risk of falls, take extra care when cleaning stairs.
- Keep hair, loose clothing and fingers away from openings and moving parts.
- Only use and replace with recommended parts and attachments.

When using as a blower:

- **DO NOT** point or direct the air hose at bystanders or animals.
- Wear eye protection and a dust mask.
- Keep children and bystanders away from the work area.

4.3 Connection to the Power Supply

This appliance is supplied with an approved plug and cord for your safety.

If the power supply cord is damaged, it must be replaced by Draper Tools, an authorised service agent or similarly qualified personnel in order to avoid a hazard.

The damaged or incomplete plug, when cut from the cord, shall be disabled to prevent connection to a live electrical outlet.

This appliance is a Class II† and is designed for connection to a power supply matching that detailed on the rating label and compatible with the plug fitted.

The value of the fuse fitted is marked on the pin face of the plug. Should the fuse need replacing, use a small plain-slot screwdriver to remove the fuse cover. Ensure the substitute is of the correct rating, approved to BS 1363/A and ASTA or BS Kite marked. This should only be performed by suitably qualified personnel.

ASTA




BSI



Important: If an extension lead is required, use an approved and compatible lead rated for this appliance. Unwind the entire cable and follow all the instructions supplied with the extension lead.

Follow all the instructions supplied with the extension lead.

Important: ALWAYS follow the extension lead instructions regarding maximum load while the cable is wound. It is recommended that the power cord and/or the extension lead are fully unwound before connecting to a power supply. A coiled extension lead generates heat which could melt the lead and cause a fire.

†Double insulated : This product requires no earth connection as supplementary insulation is applied to the basic insulation to protect against electric shock in the event of failure of the basic insulation.

It is recommended that this vacuum cleaner is used with a residual current device (RCD).

4.4 Residual Risk

The safety instructions in this manual cannot account for all possible conditions and situations that may occur. Exercise common sense and caution when using this product and protect against any additional conceivable risks.

5. Identification and Unpacking

Carefully remove the product from the packaging and examine it for any signs of damage that may have occurred during shipment. If any part is damaged or missing, do not attempt to use the product. Please contact the Draper Helpline; contact details can be found at the back of this manual.

5.1 Product Overview



- | | | |
|--------------------------|-----------------------|-----------------------------------|
| 1. Vacuum port | 8. Utility nozzle | 15. Cloth filter |
| 2. 'ON/OFF' Power switch | 9. Extension tube | 16. Adaptor for car detailing kit |
| 3. Handle | 10. Accessory storage | 17. 6 piece car detailing kit |
| 4. Power head | 11. Blower port | 18. Round brush |
| 5. 2 x latches | 12. Container | 19. Crevice tool |
| 6. 1.5M flexible hose | 13. Foam filter | 20. Car nozzle |
| 7. Plug and cord | 14. Carrying strap | |

5.2 Packaging

Keep the product packaging for the duration of the warranty period for reference should the product need to be returned for repair.



WARNING! Keep packaging materials out of reach of children. Dispose of packaging correctly and responsibly and in accordance with local regulations.

Please visit [drapertools.com](https://www.drapertools.com) for our full range of accessories and consumables.

6. Preparation Instructions

Important: Before preparing or adjusting this product, read and understand all the safety instructions listed in this manual.

Note: Remove all the accessories from inside the tank before setting up the vacuum cleaner.



Fig. 1

6.1 Setting up the Vacuum Cleaner

Important: Ensure the vacuum is unplugged from the power socket before assembling.




Fig. 2



Fig. 3

1. Release the latches (5) and lift off the power head (4).
2. Fit the required and correct filter.
 - Cloth filter (15) for dry vacuuming (refer to **Section 8.1**).
 - **NOT** suitable for wet vacuuming.
 - Foam filter (13) for wet vacuuming only (refer to **Section 8.2**). **NOT** suitable for dry vacuuming.
3. Refit the power head (4) and secure using the two latches (5).




Fig. 4

4. Insert the connector end of the hose (6) into the vacuum port (1).



Fig. 5

5. Fit the required attachment to the end of the hose.




Fig. 7

6. Connect to the power supply and press the **ON/OFF** power switch (2).

Important: Before operating this product, read and understand all the safety instructions listed in this manual. Ensure that the product is fully assembled and correctly set up for use.

- **DO NOT** operate the vacuum cleaner without the correct filter fitted.
- Empty the tank before changing between wet and dry vacuuming.

7.1 Dry Vacuuming

1. Ensure the vacuum is unplugged from the power outlet.




Fig. 8

2. Fit the cloth filter (15) over the filter cage. Ensure that it is pushed down securely and fully covers the filter cage.
 - **DO NOT** use the cloth filter for liquid vacuuming.

7.2 Wet Vacuuming

1. Ensure the vacuum is unplugged from the power outlet.
2. Remove the cloth filter (15) if fitted.




Fig. 9

3. Fit the foam filter (13) by carefully sliding the foam sleeve completely over the filter cage.

Important: When vacuuming large quantities of liquids use the crevice tool (19), **DO NOT** immerse the tool nozzle completely in the liquid to allow for adequate air flow.

7.3 Blower Function




Fig. 10

1. Ensure the vacuum cleaner is switched off and unplugged.
2. Check that the tank is empty before using the blower function.
3. Connect the flexible hose (6) to the blower port (11),
4. Connect to the power supply and turn on.

8. Maintenance and Troubleshooting

Important: Always unplug from the power supply before carrying out any cleaning, adjustments, servicing or maintenance.

- If the plug or power supply cord is damaged it must, for safety reason be replaced by Draper Tools, an authorised repairer or similarly qualified person in order to avoid a hazard.
- Clean and maintain the vacuum cleaner correctly and regularly to ensure optimum performance.
- **DO NOT** use abrasives or solvents to clean this product.
- **Wet Vacuuming** – To prevent the risk of mildew, empty the tank and clean both inside and outside. Remove the foam filter and allow to dry before storage.
- Clean the cloth or foam filter with mild soap and water and rinse well. Dry before refitting.
- The motor must be correctly ventilated during operation, so avoid blocking the air inlets.
- When not in use, store in a safe, dry and childproof location.

8.1 Troubleshooting

Problem	Possible Cause	Remedy
Vacuum cleaner not operating.	No power supply.	Check unit plugged in and power supply is working correctly.
	Faulty power supply.	Unplug and examine power cord. If damaged, contact the Draper Tools helpline for assistance.
	Power switch not on.	Press the switch on.
	Collection tank full.	Empty the tank.
Dust coming from power head	Cloth filter is missing or damaged.	Fit or replace cloth filter.
Reduced efficiency and motor noisy or vibrations noted.	Liquid at maximum level in tank.	Empty tank. Clean or replace foam filter.
	Blockage in tool, hose or tank collection inlet.	Unplug vacuum cleaner and check for blockage and clear.
	Cloth filter blocked by fine dust.	Clean or replace filter.

9. Spares, Returns and Disposal

For spare parts, servicing, and repair and replacement options, please contact the Draper Tools Product Helpline for details of your nearest authorised agent. Draper Tools will endeavour to hold any spare parts, if applicable, for seven years from the date that it sells the final matching stock item.

Any servicing or repairs carried out by unauthorised personnel or installation of spare parts not supplied by Draper Tools will invalidate your warranty.

At the end of its working life, dispose of the product responsibly and in line with local regulations. Recycle where possible.

- **DO NOT** dispose of this product with domestic waste; most local authorities provide appropriate recycling facilities.



10. Warranty

12 months from date of purchase – Visit [drapertools.com/warranty](https://www.drapertools.com/warranty) for full details.

However, if the tools are hired out, the warranty period is 90 days from the date of purchase

Contact Details

Draper Tools

Draper Tools Limited
Hursley Road
Chandler's Ford
Eastleigh, Hampshire
SO53 1YF,
UK

Delta International

Delta International BV
Oude Graaf 8
6002 NL
Weert
Netherlands

Website: [drapertools.com](https://www.drapertools.com)
Email: sales@drapertools.com
Product Helpline: +44 (0) 23 8049 4344
Telephone Sales Desk: +44 (0) 23 8049 4333
General Enquiries: +44 (0) 23 8026 6355

Please contact the Draper Tools Product Helpline for repair and servicing enquiries.

© Published by Draper Tools Limited