


100ML

GRAVITY FEED AIR GUN

09709 - GSG5-COMP-100 SPARE PARTS LISTING





100ML

GRAVITY FEED AIR GUN

09709 – GSG5-COMP-100 SPARE PARTS LISTING

Key No.	Part No.	Stock No.	Description
1	YSGG5COMP1-01	11409	Gun Body
2	YSGG5COMP1-02	11410	Needle Sealing Spring
4	YSGG5COMP1-04	11416	Needle Sleeve
5	YSGG5COMP1-05	11417	Needle Sealing Nut
6	YSGG5COMP1-06	11418	Air Flow Separating Ring
7	YSGG5COMP1-07	11419	Seal
8	YSGG5COMP1-08	11420	Nozzle Seat
9	YSGG5COMP1-09	11421	Ring
10	YSGG5COMP1-10	11422	O-Ring
11	YSGG5COMP1-11	11423	Nozzle Seat
12	YSGG5COMP1-12	11424	Air Cap
13	YSGG5COMP1-13	11425	Air Valve Spring
14	YSGG5COMP1-14	11426	Air Valve Stem
15	YSGG5COMP1-15	11427	Air Valve Gasket
16	YSGG5COMP1-16	11428	Air Valve Body
17	YSGG5COMP1-17	11429	Air Valve Sealing Nut
18	YSGG5COMP1-18	11430	Circlip
19	YSGG5COMP1-19	11431	Air Flow Adjustment Seat
20	YSGG5COMP1-20	11432	Air Flow Adjustment Knob
21	YSGG5COMP1-21	11433	Air Flow Adjustment Sealing Ring
22	YSGG5COMP1-22	11434	Air Joint
23	YSGG5COMP1-23	11437	O-Ring
24	YSGG5COMP1-24	11438	Trigger
25	YSGG5COMP1-25	11439	Trigger Pin

Key No.	Part No.	Stock No.	Description
26	YSGG5COMP1-26	11440	Flexible Pin
27	YSGG5COMP1-27	11442	Trigger Gasket
28	YSGG5COMP1-28	11443	Circlip
29	YSGG5COMP1-29	11444	O-Ring
30	YSGG5COMP1-30	11445	Spray Adjustment Valve Base
31	YSGG5COMP1-31	11446	Spray Adjustment Valve Stem
32	YSGG5COMP1-32	11447	Spray Adjustment Valve Dial
33	YSGG5COMP1-33	11448	Screw
34	YSGG5COMP1-34	11449	Needle Adjustment Seat
35	YSGG5COMP1-35	11450	Needle Set
36	YSGG5COMP 1-36	11451	Needle Spring
37	YSGG5COMP1-37	11452	Needle Seat
38	YSGG5COMP1-38	11453	Needle Adjustment Dial
39	YSGG5COMP1-39	11454	Circlip
40	YSGG5COMP1-40	11455	Connector
41	YSGG5COMP1-41	11483	Filter
42	YSGG5COMP1-42	11484	Cup Sealing Gasket
43	YSGG5COMP1-43	11485	Cup Connector
44	YSGG5COMP1-44	11486	Cup
45	YSGG5COMP1-45	11487	Cup Gasket
46	YSGG5COMP1-46	11488	Cup lid
47	YSGG5COMP1-47	11489	Cap