


1600W 135 BAR
**PRESSURE
WASHER**

00786 - PW1600/90D/RED & 98676 - PW1600/90D
SPARE PARTS DRAWING/LISTING



Key	Part No.	Stock	Description
1A	YPW1600/90D-1A	28008	Switch Assembly (Include part 1 to 2)
1			Switch Knob Decoration Line
2			Switch Knob
3A	YPW1600/90D-3A	28016	Switch Cover Assembly (Include part 3 to 4)
3			Decoration Board B
4			Decoration Board A
5	YPW1600/90D-5	10705	Front Cover
6A	YPW1600/90D-6A	10708	Switch Box Assembly (Include part 6 to 10)
6			Self-Tapping Screws St4X16
7			Switch Box Cover
8			Capacitor 0.22uF Capacitor
9			Switch Rod
10			Switch Switch
11A	YPW1600/90D-11A	11337	Motor & Pump Assembly (Include part 11 to 16)
11			Motor Front Cover
12			Self-Tapping Screws St4X16
13			Pump Assembly 1080
14			Motor Cover Bracket
15			Motor Cover Cap
16			Motor Bottom Cover
17A	YPW1600/90D-17A	11399	Wheel Assembly (ONE SIDE) (Include part 17 to 18)
17			Wheel Cap
18			Wheel
19	YPW1600/90D-19	28037	Gun Holder

Key	Part No.	Stock	Description
20	YPW1600/90D-20	11403	Bottom Housing
21A	YPW1600/90D-21A	28040	Transport Handle & Screw (Include part 21 to 22)
21			Long Handle
22			Self-Tapping Screw St4.8X20
23	YPW1600/90D-23	28073	Spray Gun Handle AG1175
24	YPW1600/90D-24	2100	Hose
25	YPW1600/90D-25	11407	Soap Bottle
26	YPW1600/90D-26	28164	Turbo Nozzle
27	YPW1600/90D-27	28165	Normal Nozzle
28	YPW1600/90D-28	28166	Spray Gun Lance AG1175
29A	YPW1600/90D-29A	28168	Cable Assembly (Include part 29 to 32)
29			Self-Tapping Screw St3.5X16F
30			Cable Outlet Plate
31			Cabel Sheath
32			Cable
33	YPW1600/90D-33	28169	Accessories Holder
34	YPW1600/90D-34	28170	Cable Hook
35	YPW1600/90D-35	28171	Cleaning Pin
36	YPW1600/90D-36	28172	Self-Tapping Screws ST4.8X16
37	YPW1600/90D-37	28174	Inlet Filter
38	YPW1600/90D-38	28175	Shock Absorbing Gasket
39	APW210	61284	Fix Brush
40	YPW1600/90D-40	28285	Self-Tapping Screws ST4X12