




5 TONNE TROLLEY JACK

03467 - TJ5LR SPARE PARTS DRAWING





5 TONNE TROLLEY JACK

03467 - TJ5LR SPARE PARTS LISTING

KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YTJ5LR-1	51134	Saddle
2	YTJ5LR-2	51397	Bracket
3	YTJ5LR-3	51506	Check Ring
4	YTJ5LR-4	51516	Bracket Axle Pin
5	YTJ5LR-5	51517	Check Ring
6	YTJ5LR-6	51522	Connecting Bar
7	YTJ5LR-7	51524	Front Axle
8	YTJ5LR-8	51526	Washer
9	YTJ5LR-9	51527	Front Wheel
10	YTJ5LR-10	51528	Spring Collar
11	YTJ5LR-11	51529	Chassis
12	YTJ5LR-12	51530	Check Ring
13	YTJ5LR-13	51531	Lift Arm
14	YTJ5LR-14	51533	Oil Cup
15	YTJ5LR-15	51537	Connector Sleeve
16	YTJ5LR-16	51571	Screw
17	YTJ5LR-17	51675	Spring
18	YTJ5LR-18	51712	Axle Pin
19	YTJ5LR-19	51755	Check Ring
20	YTJ5LR-20	51770	Check Ring
21	YTJ5LR-21	51857	Spacer Sleeve
22	YTJ5LR-22	51872	O-Ring
23	YTJ5LR-23	51879	Piston Rod
24	YTJ5LR-24	51896	Piston Top
25	YTJ5LR-25	51984	Nylon Insert Ring
26	YTJ5LR-26	52007	O-Ring
27	YTJ5LR-27	52015	Oil Cap
28	YTJ5LR-28	52049	Top Plate
29	YTJ5LR-29	52057	Screw
30	YTJ5LR-30	52062	Axle Pin
31	YTJ5LR-31	52065	M10x25 Bolt
32	YTJ5LR-32	52076	Castor
33	YTJ5LR-33	52090	Washer
34	YTJ5LR-34	52106	Lock Washer
35	YTJ5LR-35	52194	M12 Nut
36	YTJ5LR-36	52216	Check Ring
37	YTJ5LR-37	52217	Axle Pin
38	YTJ5LR-38	52281	Piston Crank

KEY No.	PART No.	STOCK No.	DESCRIPTION
39	YTJ5LR-39	52299	Screw
40	YTJ5LR-40	52308	Foot Pedal
41	YTJ5LR-41	52346	Pin
42	YTJ5LR-42	52353	R-Pin
43	YTJ5LR-43	52359	Spring
44	YTJ5LR-44	52365	Connecting Bar
45	YTJ5LR-45	52385	Pin
46	YTJ5LR-46	52387	Screw
47	YTJ5LR-47	52393	O-Ring
48	YTJ5LR-48	52399	Screw
49	YTJ5LR-49	52426	Pressure Spring
50	YTJ5LR-50	52429	Ball Cup
51	YTJ5LR-51	52585	Ball 3.5mm
52	YTJ5LR-52	52627	High Pressure Screw
53	YTJ5LR-53	52639	Metal Pad
54	YTJ5LR-54	52645	Ball 9mm
55	YTJ5LR-55	52649	Ball 6mm
56	YTJ5LR-56	52678	Oil Seal
57	YTJ5LR-57	52692	Unloading Valve
58	YTJ5LR-58	52694	Pin
59	YTJ5LR-59	52922	Axle Spring
60	YTJ5LR-60	52925	Cylinder Pump
61	YTJ5LR-61	52948	Collar
62	YTJ5LR-62	52950	PTFE Ring
63	YTJ5LR-63	52954	Mandrel
64	YTJ5LR-64	52959	Release Screw
65	YTJ5LR-65	52963	Hand Grip
66	YTJ5LR-66	52964	Washer
67	YTJ5LR-67	52966	Screw
68	YTJ5LR-68	52967	Check Ring
69	YTJ5LR-69	52968	Spring
70	YTJ5LR70	52970	Handle
71	YTJ5LR-71	52971	Lock Handle
72	YTJ5LR-72	52972	Pin
73	YTJ5LR-73	52973	Fix Shaft
74	YTJ5LR-74	52974	Mandrel
75	YTJ5LR-75	52975	Complete Pump Assy (Part 20-27 & 46-63)