



3M x 3M

# FOLDING GAZEBO

76942 - GAZ4 ASSEMBLY INSTRUCTIONS




FIG.1

**IMPORTANT:** Do not use this gazebo in high winds or extreme weather conditions. This gazebo must be erected by two people.

1. Place the gazebo upright in the centre of the area in which you wish to erect the gazebo. With a second person located on the opposite corner, lift the gazebo for clearance and walk backwards to extend the frame (Fig.1).

To improve the opening and closing action, spray some silicon lubricant on the outer legs.

**NOTE:** Take care not to pinch fingers in the sliding parts.



FIG.2

2. Lock the gazebo in place, grip the supporting leg and push the sliding mount upwards. Push the locking button in. Once the hole in the sliding mount is over the pin, it will pop out locking the upper frame in place (Fig.2).



FIG.3



FIG.4

3. Extend each leg by sliding out the lower section. Lock each leg in place with the pin (Figs.3 & 4)



FIG.5

4. This gazebo can be secured to the ground by passing a peg through the hole in the foot which is located at the end of each leg, or by securing using guy ropes supplied (Fig.5).