

**EN**Original Instructions  
Version 2 – December 2025

# OIL SUCTION GUN

## 47812

Read this manual in full before using this product and retain it for future use. Always use the latest version of the manual. Please visit [drapertools.com/manuals](https://www.drapertools.com/manuals) for the latest version.

### Intended Use

This transfer gun is designed to remove and change oil from vehicle gearboxes, axles and differentials.

Any other application beyond the conditions established for use will be considered misuse. Draper Tools accepts no responsibility for improper use of this product.


### Specification

Stock No.	47812
Part No.	A5/G
Hose length/type	300mm PVC
Plunger type	Rubber
Handle style	T-grip
Capacity	500ml

### Identification

- (1) Delivery hose
- (2) Barrel
- (3) End cap
- (4) T-handle

Please visit [drapertools.com](https://www.drapertools.com) for our full range of accessories and consumables.



## Assembly

- Attach the delivery hose (1) to the end of the suction gun.
- If the joint is tight, a light coating of motor oil can be used as a lubricant.

## Operation

- **Only** use for oil. **DO NOT** use with petrol or diesel.
- Wear appropriate personal protective equipment (PPE) such as gloves and eye protection when extracting oil.
- Place the end of the hose into the gearbox/ differential oil fill port.
- To operate the gun:
  - Pull up on the handle (4) to create suction and draw the oil into the barrel.
  - Push down on the handle (4) to add or top up a fluid.
- Fluids that are difficult to extract when cold will extract easier when warmed up slightly by operating the vehicle.
- The suction gun can be filled and used to add oil to gear boxes where the filler hole has poor accessibility.
- Whenever adding fluids ensure the gun is cleaned out before filling with clean oil.

## Maintenance & Disposal

- Keep the suction gun clean, wipe off any fluid spillage. Keep the suction tubes clean and clear of blockages. Check that all tubes, hoses and connections are in good condition before each use.
- Dispose of oil separately and in accordance with local regulations; **DO NOT** abandon it in the environment.



## Contact Details

### Draper Tools Limited

Hursley Road  
Chandler's Ford  
Eastleigh  
Hampshire  
SO53 1YF  
UK

**Website:** [drapertools.com](http://drapertools.com)

**Email:** [sales@drapertools.com](mailto:sales@drapertools.com)

### Draper Tools Europe B.V.

Oude Graaf 8  
6002 NL  
Weert  
Netherlands

**Product Helpline:** +44 (0) 23 8049 4344

**Telephone Sales Desk:** +44 (0) 23 8049 4333

**General Enquiries:** +44 (0) 23 8026 6355

Please contact the Draper Tools Product Helpline for repair and servicing enquiries.