DRAPER



EN

Original Instructions
Version 1
November 2026

2-IN-1 UTILITY KNIFE

29730

Operating the Knife




Fig. 1 - Utility Blade Position (2) to (3).




Fig. 2 - Scraper Position (4).

- **ALWAYS** retract the blade back to position (1) when not in use.

Changing the Blade

- For safety it is recommended to use a pair of pliers to hold the blade when removing or fitting.
- Replacement blades available refer to **drapertools.com** – Draper Stock No. 29880 (pack of 5) & 39698 (pack of 50).




Fig. 3 – Press and hold the release button (B) on the back of the blade holder.




Fig. 4 – Push the lever (A) to Position (2). Remove the blade carefully using a pair of pliers.




Fig. 5 - Press and hold the release button (B) in. Then carefully fit a new blade. Use a pair of pliers to lightly pull the blade outwards to check it is located correctly – a 'click' will be heard when secured.

Draper Tools, Draper Tools Limited,
Hursley Road, Chandler's Ford,
Eastleigh, Hampshire, SO53 1YF UK
Website: drapertools.com

Email: sales@drapertools.com
Product Helpline: +44 (0) 23 8049 4344
Telephone Sales Desk: +44 (0) 23 8049 4333
General Enquiries: +44 (0) 23 8026 6355

Draper Tools Europe B.V.
Oude Graaf 8, 6002 NL,
Weert, Netherlands
Website: drapertools.eu