


# UNIVERSAL CALIPER CODE 1125-600

DATA  
OUTPUT



1125-600



- Buttons: on/off, set, mm/inch, ABS, preset (+, -)
- Automatic power off, move the digital unit to turn on power
- Battery CR2032
- Data output
- Made of stainless steel
- Optional accessory: data output cable (code 7306-20, 7302-SPC1A/SPC1B, 7305-SPC2)

| Code     | Range*        | Resolution     | Accuracy |
|----------|---------------|----------------|----------|
| 1125-600 | 0-600mm/0-24" | 0.01mm/0.0005" | ±0.05mm  |

\* The range changes according to different points



working with stands




working with measuring jaws



## Half disk points (included)





Measuring external groove diameter with flat measuring face (depth  $h1 \leq 2.5\text{mm}$ )



Measuring internal groove diameter with spherical measuring face (depth  $h2 \leq 7.5\text{mm}$ )

## Conical points (optional)





Measuring center distance

Code

1125-T101

## Round shoulder points (optional)





Measuring inside diameter

Code

1125-T102

## Flat shoulder points (optional)



Measuring outside diameter


Code

1125-T103

To be continued

Continued from previous page


**Point sleeve (optional)**




**Code**  
**1125-T104**

Working with multifunctional points, ball points and screw thread points


**Spherical points (included)**




**Stands (included)**



**Measuring jaws (included)**



**Depth stop (included)**



**Multifunctional points 7392 (optional, page 26)**



**Ball points 7391 (optional, page 26))**



**Screw thread points 7381, 7321 (optional, page 26))**

