






Touch Dimmer & Receiver - Instructions

SYNDEO
by tagra®


Package Contains




Installation




Pairing Touch Dimmer & Receiver to Driver




1. Turn off power to the driver.




2. Connect the receiver unit into the side of the driver via the accessory port.




3. Remove the back of the touch dimmer using a coin.




4. Insert the battery. The + should be facing upwards as shown.




5. Replace the back of the touch dimmer.




6. Turn on power to the driver.




7. Press the button on the receiver unit. It will cause the LED to flash.



8. Using a small tool, press the button located in a hole in the top of the touch dimmer.



9. The light on the receiver unit will stop flashing, indicating the products have paired.



10. Wait 5 seconds until using the touch dimmer. Test to control lights.

Note:

- Distance between touch dimmer and receiver must be less than 10m.
- Using a "short press" on the touch dimmer will turn the lights on and off.
- Using a "press and hold" on the touch dimmer will increase the brightness.
- A second "press and hold" on the touch dimmer will decrease the brightness.

Warning against swallowing coin batteries



Unfortunately, it is not obvious when a button or coin battery is stuck in a child's oesophagus (food pipe). There are no specific symptoms associated with this. The child might:

- ▶ cough, gag or drool a lot;
- ▶ appear to have a stomach upset or a virus;
- ▶ be sick;
- ▶ point to their throat or stomach;
- ▶ have a pain in their abdomen, chest or throat;
- ▶ be tired or lethargic;
- ▶ be quieter or more clingy than usual or otherwise "not themselves";
- ▶ lose their appetite or have a reduced appetite; and
- ▶ not want to eat solid food / be unable to eat solid food.

These sorts of symptoms vary or fluctuate, with the pain increasing and then subsiding. A specific symptom to button and coin battery ingestion is vomiting fresh (bright red) blood. If the child does this seek immediate medical help. The lack of clear symptoms is why it is important to be vigilant with "flat" or spare button or coin batteries in the home and the products that contain them.