



## Indoor Lighting | Downlight Module

### Mini LED Module



### Standard LED Module



## IMPORTANT INFORMATION

- Please read these instructions carefully before installation or operation.
- Retain this manual for future reference.
- Please refer to product listing for detailed information.
- This product must be installed by a suitably competent person.
- This product should be installed in accordance with local IEE wiring regulations and building regulations.
- Remove product from packaging.
- Fully uncoil all cables.
- Ensure mains supply is disconnected before installation.
- Ensure others cannot restore the electrical power supply without your knowledge.
- Do not modify or replace connector type.
- Ensure connector is fully seated before energising.
- This product contains a light source of energy efficiency class G please refer to product - listing for detailed information.
- Do not open, modify, or repair the unit. No user-serviceable parts inside.

## SAFETY PRECAUTIONS

- This product must be installed by a suitably competent person.
- Ensure mains supply is disconnected before installation.
- Ensure others cannot restore the electrical power supply without your knowledge.
- Do not install or use the product if it is damaged.
- The LED light source is non-replaceable.
- For indoor use only.
- Use only with compatible Triac dimmers.
- Allow adequate ventilation around the luminaire.
- Do not connect or disconnect the DC connector while the mains supply is energised.
- Only use the supplied driver and connector set; compatibility with other drivers is not guaranteed.

## OPERATION

- This luminaire is compatible with leading or trailing-edge Triac dimmers.
- Use only with high-quality leading- or trailing-edge dimmers rated for LED loads. Performance may vary depending on the dimmer model.
- Minimum dimming level may vary; flicker-free operation is achieved only within the rated dimming range.
- Do not operate outside the specified ambient temperature range.
- The LED light source is non-replaceable. When product reaches its end of life the light source shall be replaced.

## INSTALLATION INSTRUCTIONS

- Ensure mains supply is disconnected before installation.
- Ensure others cannot restore the electrical power supply without your knowledge.
- Mount LED module.
- Plug the DC connector from the driver output into the corresponding connector on the LED module.
- Ensure correct polarity and a secure fit.
- Open the junction box and connect supply cables, no earth is required:
  - Brown = Live (L)
  - Blue = Neutral (N)
- Restore power and test the installation.

## **MAINTENANCE**

- Before cleaning or maintenance, ensure the luminaire is disconnected from the mains.
- Clean only with a dry, soft cloth.
- Do not use chemical cleaners or solvents.
- Do not open, modify, or repair the unit. No user-serviceable parts inside.
- The DC connector allows replacement of the driver if required. Disconnect the product from mains supply before separation.
- Only authorised replacement drivers of the same model and output characteristics should be used.

## **DISPOSAL & RECYCLING**

- This product must not be disposed of with household waste.
- Please return to an authorised recycling facility in accordance with local environmental regulations.

## **PRODUCT WARRANTY**

1. A warranty period is provided for products in normal use. For any faults arising during the period that are confirmed to be quality related by inspection by the company, a product of the same specification will be replaced for free.
2. The warranty does not cover any of the following:
  1. Any product damage due to usage not allowed in the instructions.
  2. Any product damage due to disassembling or wrong operation by the user.
  3. Severe appearance damage or deformation of the product.