

取扱説明書

4550182047363 冷蔵庫用米保存容器 約2kg用
4550002181284 冷蔵庫用米保存容器 約2kg用（海外対応 JAN）

○この取扱説明書をよくお読みいただき、正しくご使用ください。また、すぐに取り出せるところに大切に保管し、必要ときにお読みください。

取扱い上の注意

本紙では、誤った取扱いによる事故を未然に防ぐための注意事項を、マークをつけて表示しています。マークの意味は以下の通りです。

- ❗

実行しなければならない内容です。
- 🚫

してはいけない内容です。

⚠️ **注意** 軽傷を負うおそれ、または製品が故障することが想定される内容を示しています。

ご使用前

- 洗浄の際、研磨剤入りのスポンジ、金属たわし、クレンザー等は使用しないでください。表面をキズつけ本品が破損するおそれがあります。

ご使用時

- コンロやストーブなど、火や熱源のそばに置かないでください。
- 持ち運ぶ際に計量カップや上本体を持たないでください。容器が抜け落ちることがあります。
- 本品に細かいキズや割れ等を発見した場合は使用しないでください。破損するおそれがあります。
- 冷凍室やチルド室など氷点下になる場所では使用しないでください。本品が破損するおそれがあります。
- 強い衝撃を与えないでください。破損するおそれがあります。
- 食器洗い乾燥機は使用できません。熱による変形、ひび割れ、白濁または変色のおそれがあります。


ご使用後

- ❗直射日光を避けて保管してください。変色等の原因になります。
- ❗汚れがひどい場合は、塩素系または酸素系の漂白剤を薄めたぬるま湯に浸してください。漂白剤を使用する際は漂白剤に記載されている用法、用量を守りご使用ください。
- 本品を煮沸しないでください。熱による変形、ひび割れ、白濁または変色のおそれがあります。
- シンナー、ベンジン、アルコール、灯油などは使用しないでください。破損するおそれがあります。
- アルコール系除菌剤、酵素入り洗剤またはオレンジオイルなどのテルペン類を含有した洗剤は使用しないでください。破損するおそれがあります。

ご使用方法

- ご使用前に水やぬるま湯で洗浄してください。
- 洗浄する際は、柔らかいスポンジに薄めた中性洗剤で洗浄してください。
- 洗浄後は柔らかい布で水滴を拭き取ってください。
- 計量カップは回して着脱できます。取り付ける際は動かなくなるまで回してください（図）。
- 完全密閉ではないので、米以外は保存できません。

各部名称




本品の廃棄について

○廃棄時は各自治体の定める方法に従って処理してください。

品質表示			
部品	計量カップ	上本体	下本体
原料樹脂	ポリプロピレン	ABS 樹脂	AS 樹脂
耐熱温度	90℃	70℃	
耐冷温度	－20℃	－20℃	
容量	230ml	2.7L	
原産国	日本		

お問い合わせ先
株式会社 良品計画 www.muji.com
お客様室電話 0120-14-6404
平日 10:00～21:00
土・日・祝日 10:00～18:00
〒170-8424
東京都豊島区東池袋 4-26-3
ver.201807

印刷：片面 /1 色 (黒)



User Guide

4550182047363 RICE STORAGE BOX For Approx. 2kg
4550002181284 RICE STORAGE BOX For Approx. 2kg (JAN for overseas)

○Read this User Guide before using this product to ensure correct use of the product. Store this guide in an easily accessible location for future reference.

Precautions for Use

The following symbols indicate possible dangers associated with misuse of this product.
The following are the symbols and their meanings.

- ❗

Actions that must be taken
- 🚫

Actions that are prohibited

⚠️ **Caution** Misuse of this product contrary to these instructions may result in physical injury or damage to the product.

Before use

- Do not use an abrasive scouring pad, wire wool or cream cleanser to wash. Doing so may cause scratches on the surface leading to damage of the product.

When in use

- Do not place near open flame or a heat source such as kitchen stove or room heater.
- Do not carry by holding only measuring cup or upper part of the product. The container may fall.
- Do not use if there are scratches or cracks. Doing so may cause damage to the product.
- Do not use in places where the temperature is below 0℃ such as freezer. Doing so may cause damage to the product.
- Do not subject to strong shock. Doing so may damage the product.
- Do not wash in a dishwasher. Doing so may cause deformation, cracks, cloudiness and/or discoloration.



After use

- ❗Store away from direct sunlight. Not doing so may cause discoloration.
- ❗When the container is heavily stained, soak it in a chlorine-based bleach or a peroxide bleach diluted withlukewarm water. When using a bleach, follow the method and the quantity indicated on the product.
- Do not boil the container. Doing so may cause deformation, cracks, cloudiness and/or discoloration.
- Do not use thinner, benzene, alcohol or paraffin. Doing so may cause damage to the product.
- Do not use alcoholic steriliser or detergents containing enzymes or terpenes such as orange oil. Doing so may cause damage to the product.

Directions for use

- Wash with water or lukewarm water before use.
- Wash the container with a soft sponge and a diluted neutral detergent.
- Wipe off water droplets with a soft cloth after wash.
- The measuring cup can be attached/detached by turning. Turn until it doesn't go any further when attaching it, (figure)
- The container is not completely airtight. Do not store anything other than rice.

Part Names



Disposal

○Dispose of this product in accordance with the regulations of your local government.

Quality Display			
Parts	MEASURING CUP	BODY, UPPER PART	BODY, LOWER PART
Raw resin	POLYPROPYLENE (UK) /OLEFIN(US)	ABS RESIN	AS RESIN
Heat-resistance temperature	90℃	70℃	
Cold-resistance temperature	－20℃	－20℃	
Capacity	230ml	2.7L	
Country of Origin	JAPAN		

Contact Information

Please contact the store where you bought the product.

ver.201807

使用说明书

4550182047363 米用保存容器 约 2kg 用
4550002181284 米用保存容器 约 2kg 用 (海外对应 JAN)

○请在充分阅读本使用说明书的基础上再正确使用。另外，请将说明书存放于随时可以取出的场所，以备必要时再次阅读。

使用注意事项

为了预防错误使用所造成的事故，将注意事项标注记号进行说明。各标记的含义如下。

- ❗

必须执行的“强制”内容。
- 🚫

不可执行的“禁止”内容。

⚠️ **注意** 表示可能导致轻伤或产品损坏的内容。

使用前

- 清洗时，请勿使用含研磨剂的海绵、金属刷帚、去污剂等。否则可能造成表面损伤或产品损坏。

使用时

- 请勿放在炉灶、火炉等火源及热源附近。
- 请勿持量杯或主体上部进行搬移。否则容器可能会脱落。
- 若产品发现细小伤痕或裂损等请勿使用。否则可能导致产品损坏。
- 请勿于冷冻室或冷鲜室等低于冰结点的场所使用。否则可能导致产品损坏。
- 请勿施加强烈冲击。否则可能导致产品损坏。
- 请勿用于洗碗机。否则可能由于受热导致变形、开裂、发白或变色。


使用后

- ❗保存时请注意避免直射阳光，否则可能导致变色等。
- ❗污垢严重时，请用稀释氯系或氧系漂白剂的温水浸泡。使用漂白剂时，请务必遵守漂白剂产品上指定的用法、用量。
- 请勿煮沸本产品。否则可能由于受热导致变形、开裂、发白或变色。
- 请勿使用稀释剂、汽油、酒精、煤油等。否则可能导致产品损坏。
- 请勿使用酒精类除菌剂、含酶洗涤剂或橙油等含萜烯类物质的洗涤剂。否则可能导致产品损坏。

使用方法

- 使用前请用冷水或温水清洗。
- 清洗时，请使用软质海绵加水稀释中性洗涤剂进行清洗。
- 清洗后，请用软布擦去水珠。
- 量杯可旋转装卸。安装时请将量杯旋紧直至固定（图示）。
- 本产品非完全密封，请勿存放米以外的食品。

各部位名称



关于本产品的废弃

○废弃时，请根据所在地区规定的方式进行处理。

质量标识			
部件	量杯	主体上部	主体下部
原材料树脂	聚丙烯	ABS 树脂	AS 树脂
耐热温度	90℃	70℃	
耐冷温度	－20℃	－20℃	
容量	230ml	2.7L	
原产国	日本		

联系方式
无印良品（上海）商业有限公司
邮编：200040
上海市静安区南京西路 1601 号 35 楼
电话：021-6375-6677
执行标准：GB/T 30401-2013 GB 4806.7-2016

ver.201807

(縮尺：100%)