


MODEL 100



MODEL 120

Model 100  
Cod. 570660  
Cod. 570661  
96 x 57 x h 56 cm  
37.8 x 22.4 x h 22.05 in

Model 120  
Cod. 570670  
Cod. 570671  
119 x 58 x h 60 cm  
46.9 x 22.8 x h 23.6 in




ASSEMBLY  
TUTORIAL




A










- Posizionare la rete in modo tale che le barre verticali siano sul lato esterno della gabbia.
- Place the net so that the vertical bars are in the outer side of the cage.
- Positionner la grille afin que les barres verticales soient sur le côté extérieur de la cage.
- Bringen Sie das Netz so an, dass sich die vertikalen Stäbe auf der äußeren Seite des Käfigs befinden.
- Plaats het gaas op zo'n manier dat de verticale spijlen aan de buitenkant van de kooi zitten.
- Posicionar la red de modo que las barras verticales estén en el lado externo de la jaula.




B




**C****D****E**

MODEL 100




MODEL 120



G


1L



LEFT


Sinistra  
Left  
Gauche  
Links  
Izquierda

2L



H


1R




RIGHT

Destra  
Right  
Droit  
Recht  
Derecho




2R



I



J



K

