







Cod. 72085011

18x22xh 41 cm

7x8.6xh 16.1 in



**ASSEMBLING • ASSEMBLAGGIO • MONTAGE • BAUANLEITUNG
MONTAGEHANDLEIDING • MONTAJE • MONTAGEM • УСТАНОВКА**



DIRECTIONS FOR USE

MODO D'USO





MODE D'EMPLOI

GEBRAUCHSANWEISUNG GEBRUIKSAANWIJZING

INSTRUCCIONES DE USO

INSTRUÇÕES DE USO

ИНСТРУКЦИЯ ПО ПРИМЕНЕНИЮ



BAG REPLACEMENT

WARNING: To avoid the danger of suffocation, keep this bag (or covering) away from babies and children. Do not use in cribs, cots, beds, carriage, prams or playpens. This bag (or covering) is not a toy.

SOSTITUZIONE SACCHETTO

ATTENZIONE: I sacchetti di plastica possono essere pericolosi. Per evitare pericoli di soffocamento non lasciare questo sacchetto alla portata dei bambini.

REEMPLACEMENT DU SAC

AVERTISSEMENT : Les sacs en plastique peuvent être dangereux. Pour éviter tout risque d'étouffement, tenir hors de portée des enfants.

BEUTELWECHSEL

ACHTUNG: Kunststoffbeutel können gefährlich sein. Um Erstickungsgefahr zu vermeiden bitte diesen Beutel von Babies und Kindern fernhalten.

ZAK VERVANGEN

WAARSCHUWING: In verband met verstikkingsgevaar buiten bereik van kinderen houden.

SUSTITUCIÓN DE LA BOLSA

ADVERTENCIA: Las bolsas de plástico pueden ser peligrosas. Para evitar el peligro de asfixia mantenga esta bolsa alejada del alcance de bebés y niños.

SUBSTITUIÇÃO DO SACO

AVISO: Mantenha esta embalagem longe do alcance de crianças para evitar o risco de asfixia.

ЗАМЕНА МЕШКА

ПРЕДУПРЕЖДЕНИЕ: Во избежание опасности удушья, хранить в недоступном для детей месте.

