

Assembly Instructions Additions : Double Booth (RH Doors)

These instructions are to be used alongside the 'Oasis Assembly Instructions' for a single booth

When building a double booth with a shared central wall the joining post configuration is different to standard. Follow steps 1 to 8 in the standard instructions but please be aware that the frames and relevant link posts have been supplied as below.

- All additional fixing have been supplied in the kit.
- Each booth is individually powered. Power entry to each booth is on the outer side panels.
- The central shared wall are supplied with additional acoustic blocking panels. These are to be removed while installing the frames. Simply by lifting in their retaining slots, angling and removing. Please re install before fitting internal upholstered panels for best acoustic performance.

