

Selecting the correct light bulb


- Bulb Type - 3 x G9
- Maximum Wattage - 28W Eco Halogen | 3W LED
- Voltage - 240 Volts

Location

- This product is suitable for indoor use only.
- Ensure the lamp is located where the power cable will not cause an accident.
- Place lamp on a level surface.

Cleaning Care

Always switch off supply before cleaning. Clean with a soft dry cloth. Do not use abrasive materials as this may damage your product.



CLARA FLOOR LAMP
HOME4475

Instructions

Please read these instructions carefully and retain for future reference.

All our products are thoughtfully designed and expertly manufactured. So that you get the most out of your new light we offer the following guidelines to assist you.

Contents

- 1 x Base
- 1 x Shade

Important Information

- To prevent electrocution switch off at the mains supply before assembling or maintaining.
- Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated, this may cause your light fitting to overheat.
- When changing the bulb, always switch off the supply and allow the old bulb to cool down before handling. Dispose of bulbs carefully.
- The external flexible cable or cord of this luminaire cannot be replaced. If the cord is damaged the luminaire shall be destroyed.

Before Starting

Please read through these instructions before assembling product and retain for future reference. Keep all packaging until after successful installation.

Assembly Instructions

Step 1

Once unpacked, remove all packaging including plastic 't' pieces supplied between columns (keep until successful installation).

Step 2

Screw lamp stem into base at point A in a clockwise direction and tighten to secure.

Step 3

Assemble the floor lamp column by screwing together the threaded sections at points B in a clockwise direction. Repeat for point C. While assembling pull excess flex carefully through the base of the floor lamp (use only the minimum force required to draw the cable through).

Step 4

If required, carefully tighten the cord restraint at point D using a flat head screwdriver.

Step 5

Fit all the light bulbs (not supplied). Carefully attach all 3 shades as shown on point E. Take care to ensure each shade is securely attached before moving on to the next.

Step 6

The angle of the shades can be tilted as desired. (If you wish to adjust the angle of the shades again past this step, only adjust when the lamp is switched off and allow time to cool down before handling as the bulb and surrounding parts can become hot during use.)

Step 7

Plug lamp into power socket with power off. Adjust to desired position before switching lamp on.

