Selecting the correct light bulb

- Bulb Type 1 x GLS
- Maximum Wattage 28W Eco Halogen | 8W Energy Saver | 6W LED


Location

• This product is suitable for indoor use only.

Cleaning Care

Always switch off supply before cleaning. Clean with a soft dry cloth. Do not use abrasive materials as this may damage your product.





LOLA PENDANT SHADE HOME3445

Instructions

All our products are thoughtfully designed and expertly manufactured. So that you get the most out of your new light we offer the following guidelines to assist you.

Contents

• 1 x Pendant frame • 34 x 'A' type droplets • 16 X 'C' type droplets

Important Information

- To prevent electrocution switch off at the mains supply before maintaining/cleaning.
- Always be sure to use the correct type and wattage of bulbs as indicated on the pendant.
 Never exceed the wattage stated, this may cause your pendant shade to overheat.
- When changing the bulb, always switch off the supply and allow the old bulb to cool down before handling. Dispose of bulbs carefully.
- These instructions are for assembling your non electrical pendant only

Before Starting

Please read through these instructions before assembling product and retain for future reference. Keep all packaging until after successful installation.

Assembly Instructions

Step 1

Once unpacked, remove all packaging (keep until successful installation).

Step 2 (refer to fig 1 and Key)

Carefully hook all type 'C' droplets to the inner ring on the pendant frame.


Step 3 (refer to fig 1 and Key)

Carefully hook all type 'B' droplets to the middle ring on the pendant frame.

Step 4 (refer to fig 1 and Key)

Carefully hook all type 'A' droplets to the outer ring on the pendant frame.





<u>Diagrams are representative and</u> may not fully match your product.

Fig 1: Top View

