

### **Selecting the correct light bulb**


- Bulb Type - 1 x GLS
- Maximum Wattage - 42W Eco Halogen | 11W Energy Saver | 10W LED

### **Location**

- This product is suitable for indoor use only.

### **Cleaning Care**

Always switch off supply before cleaning. Clean with a soft dry cloth. Do not use abrasive materials as this may damage your product.



## **LOOPAL PENDANT SHADE**

HOME3510

# **Instructions**

Please read these instructions carefully and retain for future reference.

**All our products are thoughtfully designed and expertly manufactured.** So that you get the most out of your new light we offer the following guidelines to assist you.

### **Contents**

- 1 x Pendant frame
- 20 Flower pieces
- 20 x Stems

### **Important Information**

- To prevent electrocution switch off at the mains supply before maintaining/cleaning.
- Always be sure to use the correct type and wattage of bulbs as indicated on the pendant.  
Never exceed the wattage stated, this may cause your pendant shade to overheat.
- When changing the bulb, always switch off the supply and allow the old bulb to cool down before handling. Dispose of bulbs carefully.
- These instructions are for assembling your non electrical pendant only

### **Before Starting**

Please read through these instructions before assembling product and retain for future reference. Keep all packaging until after successful installation.

### **Assembly Instructions**

#### **Step 1**

Once unpacked, remove all packaging (keep until successful installation).


#### **Step 2**

Refer to figure 1. Carefully push stem into a slot within the central metal pendant. Place flower piece with a clear washer on each side at the end of the stem as shown on figure 1. Carefully tighten nut to secure the flower.

#### **Step 3**

Repeat step 2 for each flower until all the slots are filled.

### **Key**



**Diagrams are representative and may not fully match your product.**

