

Selecting the correct light bulb


- Bulb Type - BC GLS
- Maximum Wattage - 42W Eco Halogen | 11W Energy Saver | 10W LED
- Voltage - 240 Volts

Location

- This product is suitable for indoor use only.
- Ensure the lamp is located where the power cable will not cause an accident.
- Place lamp on a level surface.

Cleaning Care

Always switch off supply before cleaning. Clean with a soft dry cloth. Do not use abrasive materials as this may damage your product.



NELSON FLOOR LAMP

SACA1004 | SACA1005 | SACA4845

Instructions

Please read these instructions carefully and retain for future reference.

All our products are thoughtfully designed and expertly manufactured. So that you get the most out of your new light we offer the following guidelines to assist you.

Contents

- 1 x Base
- 1 x Shade

Important Information

- To prevent electrocution switch off at the mains supply before assembling or maintaining.
- Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated, this may cause your light fitting to overheat.
- When changing the bulb, always switch off the supply and allow the old bulb to cool down before handling. Dispose of bulbs carefully.
- The external flexible cable or cord of this luminaire cannot be replaced. If the cord is damaged the luminaire shall be destroyed.

Before Starting

Please read through these instructions before assembling product and retain for future reference. Keep all packaging until after successful installation.

Assembly Instructions

Step 1

Once unpacked, remove all packaging including plastic 't' pieces supplied between columns (keep until successful installation).

Step 2

Screw lamp stem into base at point A in a clockwise direction and tighten to secure.

Step 3

Assemble the floor lamp column by screwing together the threaded sections at points B in a clockwise direction. Repeat at point C. While assembling pull excess flex carefully through the base of the floor lamp (use only the minimum force required to draw the cable through). If required, secure by tightening the cord restraint at point D with a flat bladed screwdriver.

Step 4 (refer to point E)


To shade your floor lamp, unscrew plastic skirt from the lamp holder. Place shade over the lamp holder, secure using the plastic skirt.

Step 5

Refer to wattage labels on your lampholder/shade gimble to select correct bulb (not supplied) for your lamp. Use the label to ensure you have the correct fitting type, bulb shape and wattage. Screw bulb into place.

Step 6

Adjust to desired position then plug lamp into power socket with power off. Finally power on the lamp using power switch.



Diagrams are representative and may not fully match your product.

Fig 1

