

Light source remove Instructions

V1.0 Template(2021)

CONNECTED BY LIGHTING V1.0 Template (2021)			
Product Identification		Product Image	
Company Name	LUTEC	_ _	
Item code	7622220012		
Module code	7622220012M		
Product Name	DRACO		
Last modified 2021/10/30			
Step			
1. Light		Pry open the upper cover of camera, unscrew and remove the control board on camera	
3. Unscrew and remove the camera and speaker		4. Unscrew and remove the entire camera shell and pull out the connecting wire	
5. Unscrew the plastice plate and remove the drive		6. Unscrew and solder off the wires on control board	
7. Pry open the diffuso	ors	8. Unscrew and remove the reflectors	

10. Module

9. Unscrew the bolts and pull out the LED board