

Note: Servicing should only be attempted by suitably skilled personnel.
For more info about this or training courses, contact Drive Medical

	Steel Wheelchair	Travel Chair	Alu. Wheelchair	Folding Powerchair	Fixed Base Powerchair	Boot Scooter	Class 2 Scooters	Class 3 Scooters		Steel Wheelchair	Travel Chair	Alu. Wheelchair	Folding Powerchair	Fixed Base Powerchair	Boot Scooter	Class 2 Scooters	Class 3 Scooters	
Section 1: Controller																		
On/Off Switch	■	■	■															
Joystick / Wigwag	■	■	■															
Joystick Gaitor	■	■	■				■	■										
Output Plug	■	■	■															
Seal	■	■	■				■	■										
Operation	■	■	■															
Dynamic Braking	■	■	■															
Static Braking	■	■	■															
Section 2: Batteries																		
Type (SLA/AGM/Gel)	■	■	■															
Compartment	■	■	■															
Connections	■	■	■															
Wirings	■	■	■															
Battery Test	■	■	■															
Section 3: Wheels																		
Tyre Pressure		■				■												
Tyre Wear																		
Wheel Bearings																		
Hub Caps / Disks	■	■	■	■	■	■	■	■										
Wheel Nuts Tight	■	■	■	■	■	■	■	■										
Tab Washers	■	■	■	■	■	■	■	■										
Lubricated / Greased	■	■	■															
Section 4: Chassis / Frame																		
General Condition																		
Castor Assemblies							■	■										
Manual Brakes					■		■	■										
Suspension	■	■	■	■	■	■	■	■										
Steering Linkage	■	■	■	■	■	■	■	■										
Swivel Bearings	■	■	■	■	■	■	■	■										
Tiller Pivot	■	■	■	■	■	■	■	■										
Handbrake	■	■	■	■	■	■	■	■										
Footrest Lock Mechanism	■	■	■	■	■	■	■	■										
Section 5: Motor/s																		
Wiring	■	■	■															
Mounting	■	■	■															
Function	■	■	■															
Noise Level	■	■	■															
Commutator Cleaned	■	■	■															
Brushes	■	■	■															
Section 6: Upholstery																		
Seat																		
Back																		
Armpads																		
Pouch									■	■	■	■	■	■	■	■	■	
Hood Tiller																		
Section 7: Body																		
Mounting	■	■	■	■	■	■	■	■										
Condition	■	■	■	■	■	■	■	■										
Seat Mechanism	■	■	■	■	■	■	■	■										
Seat Adjustment	■	■	■	■	■	■	■	■										
Section 8: Electrics																		
Condition of Loom	■	■	■	■	■	■	■	■										
Lights	■	■	■	■	■	■	■	■							■	■		
Audible Warnings	■	■	■	■	■	■	■	■										
Charger	■	■	■	■	■	■	■	■										
Charger Connection	■	■	■	■	■	■	■	■										
Section 9: Drive Train																		
Transaxle Seals	■	■	■	■	■	■	■	■										
Transaxle Noise Lever	■	■	■	■	■	■	■	■										
Transaxle Mount Brackets	■	■	■	■	■	■	■	■										
Section 10: Test Run																		
Test Run																		