



Seat Fitting Instructions (ALL SCOOTERS)

STEP 1 - Before you insert the seat post into the base, LIFT UP THE HANDLE as shown above.



STEP 2

**Keep the handle lifted and insert
post into base.**



STEP 3

Once the post is inserted release the handle; this will then stop the seat from swivelling.