



Cirrus Powerchair Parts List

Applies to PCC18SIL (Cirrus) and UBPC18SIL (Unbranded Powerchair)



Number	Code	Description
1	Z21902-01	Joystick mount, PCC18SIL
2	Z21180-01	Cross brace support, PCC18SIL
3	Z21211-01	Seat cushion 18" , PCC18SIL
4	Z21261-01	Back cushion 18" , PCC18SIL
5	Z21301-01	Back post w/o screw set, PCC18SIL
6	Z21302-01	Screw set for back post, PCC18SIL
7	Z21464-01	Lhs motor VSI2 connector, PCC18SIL
8	Z21474-01	Rhs motor VSI2 connector, PCC18SIL
9	Z21550-01	Lhs armrest complete, PCC18SIL
10	Z21560-01	Rhs armrest complete, PCC18SIL
11	Z21600-01SIL	Rhs leg rest silver, PCC18SIL
12	Z21650-01SIL	Lhs leg rest silver, PCC18SIL
13	Z21901-01	Joystick controller VSI2
14	Z21918-01	Foldable battery tray 18" , PCC18SIL
15	Z21960-01	Battery box (pair), VSI2 connector
16	Z21405-01	Front castor wheel and fork, PCC18SIL
17	Z20454-01ST	Solid power chair wheel, PCC18SIL
18	Z19800-01	Height adj anti tip wheels, PCC18SIL
N/A	Z15910-01	One touch lap belt, PCC18SIL
19	Z20970PC	Charger

