

## WAVE PTX - Subscriptions

A simple comparison, showing the features and benefits of both the WAVE PTX BASIC & WAVE PTX SAFEGUARD subscriptions.

WAVE PTX FEATURES	WAVE PTX BASIC				WAVE PTX SAFEGUARD			
	BYOD*	DISPATCH	TLK100/TLK150	TLK110	BYOD*	DISPATCH	TLK100/TLK150	TLK110
PTT (PRIVATE AND GROUP CALLING)	●	●	●	●	●	●	●	●
PRESENCE	●	●	TX ONLY	TX ONLY	●	●	TX ONLY	TX ONLY
INSTANT PERSONAL ALERT (CALL ALERT)	●	●	●	●	●	●	●	●
SECURE MESSAGING - TEXT, IMAGE, VIDEO, LOCATION, DOCS	●	●			●	●		
VOICE MESSAGING	●	●			●	●		
TALKGROUP MONITORING		●				●		
PRIORITY TALKGROUP SCANNING	●	●	●	●	●	●	●	●
BROADCAST CALLING/MESSAGING	●	●	VOICE ONLY	VOICE ONLY	●	●	VOICE ONLY	VOICE ONLY
GEOLOCATION	●	●	TX ONLY	TX ONLY	●	●	TX ONLY	TX ONLY
LOCATION HISTORY		●				●		
LOGS (AUDIT, CALLS, MESSAGES, LOCATION)		●				●		
GEOFENCE	●	●			●	●		
QUICK GROUP FROM MAP	●	●			●	●		
EMERGENCY CALLING AND ALERT					●	●	TLK100 VIA PROG. BUTTON	●
AMBIENT AND DISCREET LISTENING					●	●	DECODE ONLY	DECODE ONLY
USER-CHECK AND USER-MONITOR					●	●	DECODE ONLY	DECODE ONLY
AREA-BASED DYNAMIC GROUP						●		
LONE WORKER								●
MAN DOWN								●
WAVE PTT LMR INTEROP	ADD ON	ADD ON	ADD ON	ADD ON	●	●	●	●
WAVE PTT STREAMING VIDEO	ADD ON	ADD ON			ADD ON	ADD ON		
WAVE PTT STREAMING VIDEO PULL FEATURE					With Streaming Video**			

\*BYOD = Bring Your Own Device (includes EVOLVE and commercial phones)  
 \*\* Comes with Video Streaming add on when used with Safeguard only



## WAVE PTX Safeguard Package Features

### Emergency Calling & Alerting

Users press a hard or soft dedicated button to initiate an emergency call with the highest priority and preemption.

### Ambient Listening

Makes it possible for dispatchers or supervisors to check on the well-being of users by remotely opening the device's microphone.

### Discrete Listening

Monitors all PTT communication between targeted user and other PTT callers.

### LMR Interoperability

Connect WAVE PTX and two-way radio systems for unified communications.

### Remote User Check

Allows supervisors or dispatchers to monitor the health of a user's device, including battery level, signal strength and location.

### User Enable/Disable

Supervisors can remotely enable or disable the PTT function on specific devices.

### Location-Based Temporary Groups (Dispatcher-only)

Adds/removes members from a talkgroup as they enter or leave a defined geographic area.

### Lone Worker

Users must interact with the device periodically. If they do not, an emergency alarm is sent as the user may be in trouble. Timings can be altered and set in the portal.

### Man Down / Fall Alert

If the user falls over or doesn't move for a predetermined amount of time, an emergency alarm is sent. Timings and Angles can be altered and set in the portal.