

How Klick Fast works

The Klick Fast System sets the standard for carrying radios, body cameras and other portable equipment.

At the heart of the Klick Fast System is a tough Connector, your key to secure, hands-free carrying solution.

It clicks effortlessly into any Klick Fast Dock, locking your device firmly in place. Rotate it to one of seven fixed positions for the perfect angle, then get on with the job.

Whether built into your gear or retrofitted, the Connector works with a wide range of holders, cases and devices.

And when it's time to undock? Just rotate and slide it free.



Have your device with a Klick Fast Connector securely on the back.



Slide the Connector into the Dock until you hear the Klick.



Rotate for comfort and convenience, 7 secure positions.



To remove, rotate the device until it is upside down.



The device can then be un-docked.