

Klick Fast Ultra-Lock Connector

A Klick Fast Connector with a double-lock for extra security. The Klick Fast Ultra-Lock Connector requires an additional action to remove the device or equipment from the Klick Fast Dock.



Have your device with a Klick Fast Connector securely on the back.



Slide the Connector into the Dock until you hear the Klick.



Rotate for comfort and convenience, 7 secure positions.



To remove, rotate the device until it is upside down.



Push your device up slightly.



Then rotate your device one further ratchet position.



The device can then be un-docked.