

FITTING INSTRUCTIONS

Remove seat from Motorcycle, strip off existing cover, trim, clips etc. from seat base.
Clean off old adhesives, de-rust and re-paint as necessary.

Pull the sides of the seat up and place centrally over the seat pad.
Pull down the cover firmly at the front of the seat. Fold under base and hold in position with 2 clips.
Repeat operation along both sides simultaneously working progressively from front to rear. Trim off surplus material and fit trim strip (if supplied). Replace Seat.
To achieve best results, seat cover must be firmly pulled over seat base working from front to rear and glued down using impact adhesive.

FITTING INSTRUCTIONS

Remove seat from Motorcycle, strip off existing cover, trim, clips etc. from seat base.
Clean off old adhesives, de-rust and re-paint as necessary.

Pull the sides of the seat up and place centrally over the seat pad.
Pull down the cover firmly at the front of the seat. Fold under base and hold in position with 2 clips.
Repeat operation along both sides simultaneously working progressively from front to rear. Trim off surplus material and fit trim strip (if supplied). Replace Seat.
To achieve best results, seat cover must be firmly pulled over seat base working from front to rear and glued down using impact adhesive.

FITTING INSTRUCTIONS

Remove seat from Motorcycle, strip off existing cover, trim, clips etc. from seat base.
Clean off old adhesives, de-rust and re-paint as necessary.

Pull the sides of the seat up and place centrally over the seat pad.
Pull down the cover firmly at the front of the seat. Fold under base and hold in position with 2 clips.
Repeat operation along both sides simultaneously working progressively from front to rear. Trim off surplus material and fit trim strip (if supplied). Replace Seat.
To achieve best results, seat cover must be firmly pulled over seat base working from front to rear and glued down using impact adhesive.