

XMReality 6 with Iristick

To use XMReality 6 with Iristick you connect your Android device to the Iristick pocket unit, which is connected to the Iristick headset. To be able to detect and use the camera and other specific features on the Iristick headset you need to use a special version of XMReality 6 **and not use the version of XMReality 6 found on Google Play Store.**

To install and run XMReality 6 for Iristick, follow these steps:

1. Download and install the special Iristick-adapted version of XMReality 6 from here:
<https://xmreality.com/download/xmreality-6-for-iristick/>
2. Download and install *Iristick Services* from Google Play Store:
<https://play.google.com/store/apps/details?id=com.iristick.smartglass.service&gl=SE>
3. Make sure you allow permissions to *Iristick Services* to ensure it detects the headset when it is connected.
4. Ensure Iristick Services is opened on you mobile device when starting XMReality 6.
5. Log in to XMReality 6 using your Enterprise account.