

Cleaning and Maintenance Guidelines

Proper care will extend the life and appearance of your SPC flooring:

Daily/Regular Maintenance:

1. Sweep or vacuum regularly using a soft brush to remove dirt and debris.
2. Clean with a damp (not wet) mop using a pH-neutral cleaner.
3. Wipe spills promptly to prevent mold/mildew growth.

Do Not:

1. Use abrasive cleaners, wax, polish, or steam mops.
2. Roll or drag heavy objects across the floor.
3. Wear heels, cleats, or shoes with sharp protrusions.
4. Expose flooring to temperatures below 32°F (0°C) or above 140°F (60°C).

Preventive Care:

1. Apply felt pads to all furniture legs and replace when dirty or worn.
2. Use protective mats under wheeled office chairs and heavy equipment.
3. Avoid direct sunlight exposure — use blinds or curtains to limit UV damage.
4. Leave at least one extra box of flooring for future repairs.