FITTING INSTRUCTIONS
PLEASE READ CAREFULLY
BEFORE ASSEMBLY AND FIXING
TRANSOM MOUNT PULL SIDE

CE
ARROW ARCHITECTURAL
Tything Road
Alcester
B496ES
14
1121-CPR-AD0191
EN1154:1996/A1:2002/AC:2006
3 8 2/4 1 1 3

warrington certifire Certification
APPROVED PRODUCT
CF 5038

1



Use the template as a guide to pre drill.

2



Arm position at rest.

3



Using the template as a guide fix one end of the track(end cap then screw).

THE TRACKMUST BE FITTED TO THE DOOR FRAME, NOT ON THE ARCHITRAVE.DOOR AND FRAME MUST BE FLUSH.

4



Slide the plastic slider block with the rivet into the track followed by the end cap and screw.

5



Pre load the arm until the thread in the arm is inline with the thread on the rivet, insert your 5mm hex key through the threaded hole in the arm and into the rivet and tighten in an anti-clockwise action.

6



Adjust speed and latch.

7



Fit cover.

8



Secure cover 2x cover screws.

ENSURE THAT BOTH THE BODY AND TRACK ARE LEVEL
(USE A SPIRIT LEVEL) ENSURE THAT THEY ARE PARALLEL.

FITTING INSTRUCTIONS

PLEASE READ CAREFULLY
BEFORE ASSEMBLY AND FIXING
PULL SIDE(FIG.1)

CE

ARROW ARCHITECTURAL
Tything Road
Alcester
B496ES
14

1121-CPR-AD0191 | EN1154:1996/A1:2002/AC:2006

3 8 2/4 1 1 3

warrington certifire certification

APPROVED PRODUCT
CF 5038

1



Use the template as a guide to pre drill.

2



Arm position at rest.

3



Using the template as a guide fix one end of the track(end cap then screw).

THE TRACKMUST BE FITTED TO THE DOOR FRAME, NOT ON THE ARCHITRAVE.DOOR AND FRAME MUST BE FLUSH.

4



Slide the plastic slider block with the rivet into the track followed by the end cap and screw.

5



Pre load the arm until the thread in the arm is inline with the thread on the rivet, insert your 5mm hex key through the threaded hole in the arm and into the rivet and tighten in an anti-clockwise action.

6



Adjust speed and latch.

7



Fit cover.

8

MADE IN BRITAIN



Secure cover 2x cover screws.

ENSURE THAT BOTH THE BODY AND TRACK ARE LEVEL
(USE A SPIRIT LEVEL) ENSURE THAT THEY ARE PARALLEL.

01.07.13/1

LEFT HAND HINGE



CAUTION:DO NOT UNSCREW ADJUSTERS MORE THAN 3 TURNS FROM FULLY CLOSED POSITION

FITTING TEMPLATE ONLY

FITTING INSTRUCTIONS ON SEPARATE SHEET.

ARROW ARCHITECTURAL
Tything Road
Alcester
B496ES
14

1121-CPR-AD0191 | EN1154:1996/A1:2002/AC:2006

3 8 2/4 1 1 3

APPROVED PRODUCT
CF 5038

Max opening 120°

IMPORTANT NOTES

1/ THE FACE OF THE DOOR MUST BE FLUSH WITH THE DOOR FRAME.
2/ THE SLIDE TRACK MUST BE SECURELY FITTED TO THE DOOR FRAME DO NOT FIT ONTO THE ARCHITRAVE.
3/ THE CLOSER AND TRACK MUST BE LEVEL(USE A SPIRIT LEVEL)TO ENSURE THEY RUN PARALLEL.

MADE IN BRITAIN

RIGHT HAND HINGE



CAUTION:DO NOT UNSCREW ADJUSTERS MORE THAN 3 TURNS FROM FULLY CLOSED POSITION

D.O.P download available at www.arrow-architectural.com

01.07.13/1

TRANSOM(PULL SIDE)





CAUTION:DO NOT UNSCREW ADJUSTERS MORE THAN 3 TURNS FROM FULLY CLOSED POSITION





FITTING TEMPLATE ONLY
FITTING INSTRUCTIONS ON SEPARATE SHEET.





IMPORTANT NOTES

1/ THE FACE OF THE DOOR MUST BE FLUSH WITH THE DOOR FRAME.
2/ THE CLOSER MUST BE SECURELY FITTED TO THE DOOR FRAME DO NOT FIT ONTO THE ARCHITRAVE.
3/ THE CLOSER AND TRACK MUST BE LEVEL(USE A SPIRIT LEVEL) TO ENSURE THEY RUN PARALLEL.

D.O.P download available at www.arrow-architectural.com

ARROW ARCHITECTURAL
Tything Road
Alcester
B496ES
14

1121-CPR-AD0191 EN1154:1996/A1:2002/AC:2006

3824113

APPROVED PRODUCT
CF 5038

Max opening 120°