Light source remove Instructions

V1.0 Template(2021)

Product Identification		Product Image
Company Name	LUTEC	
Item code	5104003012/LS_10400AM 5104003032/LS_10400AM 5104005118/LS_10400BM	
Energy efficiency class	D	
Product Name	GEMINI BEAMS	
Last modified	2025/2/27	

Notice: The light source is only exchangeable by a professional.

1. Use a hexagonal wrench to unscrew the two set screws and remove the plastic plate.

2. Use a flat-blade screwdriver to loosen the LN wire screws on the terminal and remove the brown and blue wires.

3. Use a Phillips screwdriver to remove the two screws and a sawtooth screw.

4. Remove the radiator and the driver fixed with 3M glue.

5. Use a cross screwdriver to unscrew the four screws on the two light panels.

6. Remove the light-emitting board and driver