

DRAPER

EN

Original Instructions
Version 1
April 2025

EAR **DEFENDERS**

28282



**UK
CA** **CE**

EN 352-1:2020

1. General Information

Ensure these ear defenders are fitted, adjusted and maintained in accordance with these instructions, and regularly inspected for serviceability. Ear defenders should be worn at all times in noisy surroundings.

Important: The fitting of hygiene covers to the cushions may affect the acoustic performance of the ear defenders. Glasses and hair trapped between the cushions and the ear may also affect performance.

2. Fitting and Adjustment

Position the ear defender cups at the bottom of the slots in the headband. Fit the cups over the ears with a vertical orientation and slide the headband down until it touches the top of the head. The headband may need to be tightened during prolonged use.

3. Maintenance and Storage

This product should offer adequate protection for two to three years. During transportation or when not in use, store the product in a container out of direct sunlight, away from chemicals and abrasive substances, and so that it cannot be damaged by hard surfaces. Clean the cushions with warm soapy water after use; do not use solvents or abrasive cleaners. Ear defenders, and in particular cushions, may deteriorate with use and should be examined at frequent intervals for cracking and leakage.

Important: If an allergic reaction occurs from skin contact with this product, move to a quieter area and remove the ear defenders.

4. Explanation of Symbols



Single Number Rating
(protection level)



CE – European Conformity



UKCA – UK Conformity Assessed

Helpline: +44 (0) 23 8049 4344 Sales Desk: +44 (0) 23 8049 4333 General Enquiries: +44 (0) 23 8026 6355
Website: drapertools.com Email: sales@drapertools.com

Draper Tools Limited

UK: Hursley Road, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF, UK

EU: Oude Graaf 8, 6002 NL, Weert, Netherlands

Notified Body No: 2754

Alienor Certification

ZA du Sanital - 21 Rue Albert Einstein - 86100 Chatellerault, France